BabyRest®

Journey 2-in-1 Travel Cot User Guide



IMPORTANT

BEFORE ASSEMBLING THIS COT READ AND UNDERSTAND THE INSTRUCTIONS.

Do not use mattress other than the one supplied by the manufacturer. Incorrect mattress can cause death.

Use only accessories as recommended by the manufacturer.

Ensure the top rails and base are fully locked.

Stop using this cot if any part of the cot is broken, torn or missing.

KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.



IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

A WARNING:

- · Infant should be placed to sleep on a firm, flat surface;
- · Place infant on their back when using this product;
- Do not put objects or accessories in an infant's sleep environment;
- Do not place this product near a blind, cord, strap or similar item that could become wrapped around an infant's neck.
- This bassinet should be removed before the child can sit up.
- Never place a child in the cot when this bassinet is in place.
- Keep children away while assembling/disassembling the cot
- WARNING: do not use the bassinet function when the infant begins to push up on hands and knees or has reached 9kg, whichever comes first.
- USE ONLY THE MATTRESS SUPPLIED BY THE MANUFACTURER, INCORRECT MATTRESSES CAN CAUSE DEATH.
- Mattress size: 94 x 52 5 cm
- Use only accessories as recommended by the supplier.
- Ensure that the top rails and base are always fully engaged and the product is correctly assembled before use.
- Do not use this cot if any part of the cot is broken, torn or missing.
- Check underneath the mattress for instructions for assembly and locking procedures.
- Do not add an extra mattress as this may cause suffocation.



WARNING:

IMPORTANT! KEEP FOR FUTURE REFERENCE READ CAREFULLY.


WARNING: BEFORE USE, REMOVE AND DISPOSE OF ALL PLASTIC BAGS AND PACKAGING MATERIALS AND KEEP THEM OUT OF REACH OF CHILDREN.

- WARNING: The cot is intended for use for children aged: between birth up to 36 months.
- WARNING: When the mattress base is in the highest position the cot is designed for use by children of 0-6 months (weighting up to 9kg). When a child is able to sit, kneel on or to pull themselves up, the lowest mattress position is the safest.
- WARNING: Before using in Bassinet mode (higher mattress base) make sure that the zip is completely closed and secured.
- WARNING: To prevent the risk of fire, do not use the folding cot near naked heat sources, bar heaters, open fires or exposed flames.
- WARNING: Do not use the cot if any parts are broken, ripped or missing, and only use spare parts approved
 by the manufacturer. Check this product regularly before using it, and do not use it if any part is loose or missing
 or if there are any signs of damage. Do not substitute parts. Contact the manufacturer if replacement parts or
 additional instructions are needed.
- . WARNING: Do not use more than one mattress in the cot.
- WARNING: Only use the mattress sold together with this cot. Do not add a second mattress above this one due to a risk of suffocation. Infants can suffocate on soft bedding. Avoid placing pillow or similar items under sleeping infant for additional comfort.
- Do not adjust the height of the cot when the child is in it.
- The cot is ready for use only when the locking mechanisms are engaged. Make sure they are securely fixed before using the cot.
- The lowest position of the bed base is the safest. The base should be moved to this position as soon as the baby is old enough to sit up.
- baby is old enough to sit up.

 All components must be correctly secured. Connections must be regularly checked and tightened, if necessary.
- When the child is able to climb over the sides to get out of the cot, this cot is no longer suitable for them.
- All opening and adjustment operations and the installation of accessories must be carried out by an adult .
- Before using always check that both sides of the cot are securely in place and that the cot opening mechanism engaged, as illustrated in the instrutions.
- Do not move the product when the child is in the cot.
- Do not leave anything on the folding cot (such as toys) that provide a foothold.
- Do not place more than one child at one time in the cot.
- Do not let other children play unattended close to the cot.
- Do not place the cot on to a sloped surface with your child inside.
- To prevent it becoming trapped, do not place the cot close to walls or obstacles.
- $\bullet \, \text{Keep the folding cot clear of trailing cables and hanging cords.} \, \text{Do not position close to windows where cords,} \\$
- curtains or similar could pose suffocation or choking hazard.


 *To avoid all risks of strangulation, never give children objects with cords or strings attached, or leave them within their reach. Prolonged exposure to direct sunlight can cause the colours of the fabric to fade. After a prolonged exposure of the product to high temperatures, wait a few minutes prior to putting your child in it.
- . Do not close the cot when the child is in it.
- Keep the product out of reach of children when it is not in use.
- When cot at the highest position, the height of the inside of the cot should be at least 200MM.
- The cot should be placed on a horizontal floor;
- Young children should not be allowed to play unsupervised in the vicinity of a cot.
- Keep medication and small items that a child could choke on, away from the cot.
- The folding cot with padded rims should not be used if the covering material has been bitten through.

Parts List



Travel Cot Assembly

Step 1: Separate the end panels to unfold the Travel Cot.



Step 2: Raise each side rail until you hear a distinct click, indicating that it is securely locked into position. Apply gentle downward pressure on the top of each rail to confirm it is locked. The rails should remain upright and not fold when pressed.




Step 3: Push down firmly on the bottom rails until the base is fully flat and is correctly positioned.






Travel Cot Assembly

Step 4: Open the mattress




Step 5: Place the mattress into the base of the travel cot. Weave the velcro tabs on the underside of the mattress through the base fabric, and fasten underneath.




Your Journey Travel Cot is ready for use! Before using it, check that the cot is fully assembled and all locking devices are fully engaged.

Bassinet Assembly

Step 1: Remove the mattress.




Step 2: Open the bassinet fabric and ensure the support board is rotated into the middle of the bassinet.



Bassinet Assembly


Step 3: Place the mattress into the Bassinet base. Weave the velcro tabs on the underside of the mattress through the base fabric, and fasten underneath.



WARNING: The bassinet should NOT be used once the child is able to sit up.

Bassinet Assembly


Step 4: Secure the Zip-in Bassinet by attaching it to the zipper underneath the top rail of the travel cot.



Fasten the buckle located at the end of the zipper, and fold the Velcro tab over the buckle.









Base Storage & Pocket

When the Journey Travel Cot is set up with the zip-in bassinet, additional storage features can be used for convenience.

WARNING: Do not use these storage features when the travel cot is configured with the mattress in the lower position.




Locate the side of the Travel cot with the zip-opening side.
Unzip fully and fold the mesh flap up. Connect it to the press studs by the top rail.
This creates storage room in the space under the Bassinet and the side pocket.





Note: Maximum weight capacity: Base storage: 10kg, Storage pocket: 2kg

Mosquito Net Assembly

Place the mosquito net over the top of the Travel Cot, ensuring it is correctly oriented. Locate the fabric loops in the middle of each long side and secure them around the top rails of the Travel Cot. Fasten the elastic loops on each corner.








How to fold

Step 1: Remove the mattress.


If the Travel Cot has the zip-in Bassinet installed, remove it by unfastening the buckle, then unzip the bassinet from the Travel Cot frame.

Fold the mattress and bassinet separately, and place aside.




Step 2: Locate the buttons under the centre of both Top rails, and press to allow the Top rails to fold downwards.

Step 3: Lift up the base rails until they fold upwards, and allow the Travel Cot to partially fold.



How to fold

Step 4: Place the folded Mattress & Bassinet inside the partially folded Travel Cot, ensuring they will not obstruct the folding, then fully fold the Travel Cot. Secure the straps & press studs on both ends to lock it closed.



Care & Maintenance

Mattress Cover: Gentle machine wash up to 30°C. Line Dry or Gentle Tumble Dry.

Travel Cot fabrics: Wipe using warm water and a mild detergent.

Frame: Wipe using warm water and a mild detergent

Ensure the product is fully dry before use or storage.

Warranty

BabyRest provides the following warranty for all genuine products purchased in Australia or New Zealand for domestic household use.

Unless stated explicitly, BabyRest products are designed for domestic household use only, and are not designed for use in commercial applications such as childcare centres, hospitals, shopping centres, etc.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

In addition to the rights that are available to consumers under the Australian Consumer Law, this BabyRest product comes with a 3 year warranty which applies from the date of purchase.

This warranty does not cover change of mind exchanges or returns. This warranty guarantees that your BabyRest product/s are free from manufacturing and/or material defects provided they are used in accordance with the intended use, during the period of the applicable warranty term.

The warranty is non-transferable and immediately expires if the BabyRest product is sold, given away, or obtained by anyone other than the original purchaser.

This warranty is limited to consumer buyers of the product for their personal use, personal family or household purposes. This warranty does not extend to unauthorised purchasers of the product intended for resale or for purchasers who intend to use this product for commercial use such as a childcare centre environment (unless stated explicitly for commercial use), and rental of the product to others.

Exclusions

The following are not covered by the warranty policy:

- Defects caused by ordinary wear and tear by everyday use, natural discolouration of materials over time or by not following the cleaning & maintenance instructions
- Damage caused by accidents, improper use, negligence, fire, contact with harmful liquids or another external cause
- Damage caused by another product, including accessories
- 4. Damage by service or repair by an unofficial representative of BabyRest
 - Thef
- Air transportation or freight damage

Safety is a vital part of the design and development of BabyRest product. All BabyRest products supplied in Australia and New Zealand comply with the mandatory requirements under Australian law.

Making a Warranty Claim

To make a warranty claim, owners should contact us by email to support@babyrest.com, or phone +613 8459 2757.

The following information must be supplied when making a warranty claim:

- 1. A detailed description of the issue/fault, including any photos or videos to support the claim
- 2. A clear, legible copy of the original proof of purchase, clearly showing the date and store of purchase



BabyRest

+61 3 8459 2757 info@babyrest.com 36 Sunline Drive, Truganina, VIC 3029 BabyRest.com

