

BUSH

STORAGE

USER GUIDE:
LID ORGANISER POUCH

SKU: BS-POUCH

IT'S TIME TO ORGANISE YOUR TRIP!

Elevate your organisation with our range of Quick Release Organiser Pouches. We've created a handy series of pouches that mount to the 'Lid Organiser Panel' on the underside of your BUSH Storage Crate lid.

It's time to pick your sizes and snap on a few pouches to completely tailor your storage setup when on the road. So let's get started!

GO BUSH



USER GUIDE CONTENTS

Page 4: WHAT'S IN THE BOX

Page 5: MOUNTING YOUR LID ORGANISER POUCH

Page 10: CARE GUIDE & WARRANTY INFORMATION



1. WHAT'S IN THE BOX

- 1x Lid Organiser Pouch: Nice and simple huh!

TOOLS REQUIRED: None, just your two hands.



2. MOUNTING YOUR LID ORGANISER POUCH

STEP 1: INSERT THE ATTACHMENT STRAPS

- On the back of your Pouch, you'll find two attachment straps that feature a steel fitting.
- Locate the row of holes on the **BUSH Storage Lid Organiser Panel** that you want to line up with the top of the pouch when mounted.
- Insert the two steel fittings into the this row of holes. Choosing the holes that line up with your Pouch Attachment straps the best.



STEP 2: FEED THE STRAPS

- Feed both of the attachment straps down the back of the Lid Organiser Panel.
- Pull the steel fittings through the lowest hole that the straps will allow.



STEP 3: ATTACH!

- Locate the plastic loops on the lower part of your pouch.
- Rotate the steel fitting so it is running lengthwise and feed it through the plastic loops. Once fed through the loop, return the steel fitting to it's normal widthwise orientation.



STEP 4: SUCCESS!

- All done!



CONGRATS, YOU'RE READY TO ROLL!

CONGRATULATIONS, YOU'VE SUCCESSFULLY ELEVATED YOUR STORAGE POTENTIAL BY MOUNTING THE LID ORGANISER POUCH.

Now it's time to zip it open and throw in all the gear you can't leave home without. To help with this, we've made a full range of Quick-Release Storage pouches in handy sizes. Head on over to bushstorage.com to check out all the options. Have fun!



CARE GUIDE:

1. Always wash your gear: Salt & dirt will break down your gear fast if left unwashed after a trip. Make sure you regularly clean your BUSH Storage gear.

2. Remove when not using: If you aren't planning on any adventures for a while, then get your gear off the roof or out of the weather and store away somewhere safe.

3. Never overload: Our products are designed to carry outdoor gear, not bricks. Do not overload the Organiser Pouch, or use for industrial or heavyweight transport / storage.

4. Do not leave moisture in your Storage Crate: Although our pouches are made from mold resistant materials, moisture locked in your storage crate for long periods may cause damage. Make sure you air out your storage case after each trip!

5. Hand Wash ONLY: Hand wash your pouch in cold water with a very small amount of light soap.

6. Please follow this guide closely: Always ensure that both your Lid Organiser Pouch and any other BUSH Storage gear are installed correctly and securely mounted before traveling.

WARRANTY INFO:

- » Your BUSH Storage product is covered by our trusted warranty for 12 months after purchase.
- » This warranty only covers the original purchaser when purchasing from an official reseller of BUSH Storage products. It cannot be transferred.
- » This warranty covers your gear for all adventures against manufacturing and material defects.
- » The warranty does not cover:
 - Damage caused by incorrect use, installation or overloading.
 - Damaged cause by salt, dirt or neglecting to wash your gear.
 - Damaged caused by cleaning products that do not feature a neutral PH level.
 - Damage caused by permanent storage use, products permanently left outside stationary (not on a vehicle) for prolonged periods, commercial use, marine or any other use outside recreational, outdoor and camp storage.
- » Continued on next page

WARRANTY INFORMATION CONTINUED:

A. **Warranty and Warranty Periods.** BUSH Storage warrants to the original end user (“Customer”) that BUSH Storage products will be free from faulty manufacturing or defects in workmanship including materials. BUSH Storage Products are covered by this limited product warranty (Limited Warranty) for a period of 12 months commencing from the original date of purchase.

This Limited Warranty is non-transferable and covers only the original end purchaser of the applicable Product. Proof of purchase in the form of the original purchase receipt or packing slip is required for warranty validation. Please note that BUSH Storage cannot be held liable, in any manner, for damages to your personal property resulting from any misuse or improper care and maintenance of the Product.

B. **Obligation Under Warranty:** BUSH Storage’s sole obligation under the above warranty shall be to repair or replace products and parts during the warranty period. If a substantial defect in material and/or workmanship arises and a valid warranty claim is received by BUSH Storage within the Warranty Period, BUSH Storage will replace or repair the defective Product. If the item is unable to be repaired or replaced, then another model of similar or better specifications may be substituted. In the unfortunate event where repair or replacement is not available, BUSH Storage will issue you with a full refund of the purchase price (shipping and handling are non-refundable).

C. **DISCLAIMER OF ALL OTHER WARRANTIES:** NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, ARE GIVEN, AND FELDON SHELTER EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES, INCLUDING AND WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to particular end users.

D. **Limitations:** This Limited Warranty applies only to the normal use of the covered BUSH Storage Product, in accordance with the written user guide provided. Not including damage caused by misuse or abuse, wear and tear, corrosion, extreme weather, UV damage, accidents, incorrect set up, damage caused by cleaning products etc. BUSH STORAGE SHALL NOT UNDER ANY CIRCUMSTANCES WHATSOEVER BE LIABLE TO ANY PARTY FOR LOSS OF PROFITS, LOSS OF INFORMATION OR DATA, DIMINUTION OF GOODWILL, OR ANY OTHER SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES WHATSOEVER WITH RESPECT TO ANY CLAIM IN CONNECTION WITH FELDON SHELTER PRODUCTS AND/OR PARTS. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to particular end users.

E. **What May Void the Warranty:** This Limited Warranty shall be null and void in the following circumstances:

1. Modification or repair of any BUSH Storage product by the end user or any third party; or
2. Improper use or installation, failure to conduct regular checks, maintenance or cleaning, or damage by accident or neglect, of any BUSH Storage product by the end user or any third party; or
3. Failure of the end user or any third party to exercise caution to protect any BUSH Storage product from conditions beyond those for which the product was intended or
4. A BUSH Storage Product purchased through non-authorized dealers and/or online auction websites; or
5. Failure by the end user to follow the Return Appointment Process set forth below.



ORGANISE YOUR TRIP.