





Instant Flags - Safer Racing - Fully Encrypted

*This device is an enhancement to and not intended as a replacement of actual human flagging or other existing warning systems





866-301-7223 www.raceceiver.com





Basic Instructions

Advanced instructions online

Avoid prolonged exposure to direct sunlight

Charge Before Initial Use!



Do Not Overcharge Battery must be charged every 6 months



Channel must be set to receive flags!

Power/PWR - LED

- Press and Hold PWR to turn on or connect power cable
- Battery LED Green/Yellow/Red = charge level
- Battery LED Flashes when charging

Brightness

- Press Up/Down to change brightness
- 8 Levels are available
- Wait 3 Seconds to confirm brightness

Channel/CH

- Press CH to show current channel
- Press CH then Up/Down to change (1-5)
- Wait 3 Seconds to confirm channel

Last Flag/Power Off

- Press PWR to see the Last Flag/Battery level
 - Press PWR and **HOLD** for 8 secs to turn off
- Auto powers down after 2 hours idle



