

## LUXE ELECTRIC BARBER CHAIR

product manual




On behalf of **J&J Barber Supply Co**, we thank you for choosing our premium electric barber chair for your shop. We're thrilled to have you as a customer and we hope that our product exceeds your expectations. Our team takes pride in delivering high-quality, durable products that are designed to provide the ultimate comfort and convenience for your clients. We appreciate your trust in our brand and we look forward to serving you again in the future.

We would like to extend an invitation to our customers to reach out to us with any questions or concerns as we continue to update our product manual. Our team is available to provide further assistance through phone or video call, as we are more than happy to showcase all the features and functions of our premium furniture. Please do not hesitate to contact us, as we are committed to ensuring that our customers receive the highest level of satisfaction with our products and services.

J&J Barber Supply Co

7888 Cherry Ave #G Fontana, CA 92336 call/text (909) 550-0404 sales@jjbarbersupply.com

## product unboxing



- Inspect the crate for any damage or signs of tampering before opening it
- Use a pry bar or a hammer and chisel to remove the stapled wooden panels from the crate
- Take off any metal strapping or bands that may be holding the crate together (if applicable)
- Carefully lift the top off the crate, be sure to use caution when removing the panels to ensure no damaged during this process
- Once the top is removed, remove the side wood panels and unpack the contents of the crate, checking for any damage or missing items as you go
- The crate is particularly large and heavy, we strongly encourage enlisting the help of a second person to assist with the opening process

## product assembly & handling

Upon receipt, please note that the chair will arrive partially disassembled without the foot rest assembly (which is highlighted in yellow). To assemble the foot rest, please utilize the tools and hardware provided to securely attach the two foot pegs to the foot rest assembly, and then attach the entire assembly to the chair. its recommended to power the chair and raise the footrest for this step. When lifting the chair out of the crate and positioning it, it is crucial to handle the chair from the green highlighted area located at the bottom of the side panels. Under no circumstances should the chair be lifted from the red highlighted area, which includes the arm handles. Additionally, it is important to note that the swivel/pump brake of the chair will arrive in the lock position, which is engaged from the factory. If the chair swivels freely left or right, connect the chair to an electrical source and tap on the swivel/pump brake to lock the chairs rotation. This not only prevents the chair base from swiveling but also ensures that the hydraulic pump is securely locked in place, preventing any sliding or potential





## product operating instructions



- BACKREST SWITCH: precise adjustment control of the backrest
- FOOTREST SWITCH: precise adjustment control of the footrest
- HOME: resets the backrest and footrest back to the original seating position
- MEMORY BUTTONS: adjust your seating position to your preferred angle
  utilizing the backrest and footrest switches. To preserve your preferred
  position, hold down the memory button. To update the memory function
  with a new position, press and hold the button once you have adjusted your
  seating to your desired angle
- USB POWERED INPUT: plug in any electronic device i.e. phone charger, etc.
- POWER SWITCH: primary on and off switch
- SWIVEL BRAKE: press the rotation lock release mechanism to unlock the chair's rotation, thereby enabling a left and right swivel range of up to 320 degrees
- RAISE/LOWER CHAIR: press and hold to adjust the chair's height to your