






EVER ADVANCED

INSTRUCTIONS | Camping Table (TA-97430L)


TABLE PARTS



- ② Assemble top tubes (figure 1) then clip them onto the four corners of the leg frame by aligning the holes on the tubes to the pins on the frame (figure 2).



- ① Spread the leg frame out until the sliders reach the stop screw.



- ③ Attach the table top by inserting the top tube ends into the plastic tubes on the bottom sides of the table top.

**EVER ADVANCED,
EVER FEARLESS**

Warranty

The EA Camping Table is covered by 12-month quality warranty.

Contact Us

Website: www.everadvanced.com

Email: info@everadvanced.com

@everadvanced

@everadvanced

Safety Tips

- This table holds a maximum weight of 66lbs/30kg. Do not exceed.
- Please pay attention to safety during setup and folding to avoid clipping fingers.
- Please do not exceed the maximum weight capacity of the product during use.
- Please avoid collision during transportation.
- Children should be used under adult supervision.