




ENGINE CLEANER

- Engine cleaner before oil change
- Eliminates deposits
- Reduces maintenance costs
- Perfect for maintenance
- Recommended frequency of use: at each oil change

● **PACKING UNIT:**  300ml



- 1 - Pour ENGINE CLEANER into the crankcase, 10% to 15% of your capacity.
- 2 - Let the engine idle for 15 min.
- 3 - Drain and replace the oil filter.