

Dog Agility Seesaw



Assembly Instructions

Thank you for your purchase! Our goal at Better Sporting Dogs is to bring fun, quality equipment to dog enthusiasts just like ourselves. Agility training is a fantastic way to train your dog both mentally and physically and deepen the bond you have with your dog.

Please see the assembly instructions below. If at any point you need assistance in assembly or have any questions or concerns, we can be reached at: support@bettersportingdogs.com

***Please note:** While this equipment is great for use both indoors and outdoors, prolonged exposure to the elements will cause it to wear out more quickly. To ensure your equipment has the longest lifespan possible, it is recommended that you store it indoors when not in use.

To assemble: Remove the seesaw from the packaging. Unfold the wooden boards. Push the 2 silver push pins (circled in red) into the holes on the black metal board brackets to secure the wooden boards in the extended position. **Ensure both silver push pins are fully inserted.** Finally, straighten out the black metal base legs and clip the plastic feet (circled in red) on the bottom of the stand.

