



## How to use your Darfon Charger

1. Plug the charger into the bike **first** and then into the wall.
2. A solid green light means your battery is fully charged.
3. A flashing red light is perfectly normal. It means the battery is charging.

Solid red light	Initial charge, battery is connected.
1 red flash	<20% Charged
2 red flashes	20-39% Charged
3 red flashes	40-59% Charged
4 red flashes	60-79% Charged
5 red flashes	>80% Charged
Solid green light	100% Charged (Time to ride!)

4. If your charger **flashes** yellow at any point, that means that the battery or charger has had a failure. If this takes place, please contact Ari at (801) 471-0440 or [Questions@Ari.com](mailto:Questions@Ari.com).
5. Unplug from the wall before unplugging from the bike.

## Troubleshooting

1. If there is no initial red light
  - A. **Confirm** that everything is plugged in.
  - B. If everything is plugged in, contact the dealer.
2. If the charger **flashes** red but the battery is not charging, contact the dealer.
  - A. Avoid quickly plugging or unplugging the charger for short periods of time.

## Helpful tips

1. Supervise children near the product.
2. Only use the Darfon charger to charge the Darfon Battery.
3. Do not open the Battery or Charger.
4. Protect the Battery and Charger from humidity.
5. If Charger is not in use, remove it from the power supply to avoid over voltage.
6. If Charger is damaged in any way, do not use it.
7. Only use indoors.
8. Do not expose your battery pack to water or rain, or allow them to get wet. This could damage the tool and battery pack. Do not use oil or solvents to clean or lubricate your battery charger. Keep away from extreme temperatures.
9. Any questions- please reach out to Ari at (801) 471-0440 or [questions@Ari.com](mailto:questions@Ari.com).