

Model 1651 OWNER'S MANUAL



Canvas Wall Enclosure Accessory Fits Cabin Tent Model 6133 (Sold Separately)

Visit us online at: www.KodiakCanvas.com

Important! For safe and proper assembly, use, and care, read and follow all instructions. Everyone who uses this tent should first read this manual.

<u>No Fire</u>

This tent is flammable. Keep all flame and heat sources away from the tent fabric. Never place a stove, campfire, or any other flame source in or near your tent. Never use, light, or refuel a stove, lantern, heater, or any other heat source inside your tent. Death by carbon monoxide poisoning and/or serious burns are possible.

Ventilation

Maintain adequate ventilation inside your tent at all times. Death by asphyxiation is possible.

Anchor

This tent is not free-standing. If not properly anchored it will collapse. Always anchor your tent properly to reduce the risk of loss or injury to the tent or occupants.

Campsite Choice

Carefully consider the possibility of falling rocks or tree limbs, lightning strikes, flash floods, avalanches, strong winds, and other objective hazards when choosing a campsite to reduce the risk of loss or injury to the tent or occupants.

<u>Children</u>

Do not leave children unattended inside a tent or camp. Do not allow children to assemble or disassemble the tent.

Do not allow children to remain closed-up in a tent on hot days.

Do not allow children to swing on, or hang from any part of this tent, or guy ropes.

Failure to follow these warnings may result in injury and/or death.

Before You Set Out

• You should assemble this tent at least once before your trip to familiarize yourself with the process, and make sure all the parts are in good condition.

At least two adults are required for set up.

IMPORTANT

The tent must be completely dry before storage! STORING A WET OR DAMP TENT, EVEN FOR A SHORT TIME, WILL RUIN IT AND VOID THE WARRANTY.

Kodiak Canvas Limited Lifetime Warranty

This product is warranted, to the original purchaser, to be free of defects in materials and workmanship for as long as you own the product. This product is made with quality materials and expert workmanship but is not indestructible. This warranty does not cover damage attributed to or resulting from normal wear and tear (e.g. exhausted zippers), natural hazards (e.g. weather, animals), abuse (e.g. mold, mildew, burns, ultraviolet), or alterations or modifications of any kind. If your product is found defective, we will repair or replace it free of charge. Charges for shipping your product to Kodiak Canvas will be your responsibility. We reserve the right to make substitutions if parts are unavailable or obsolete. If your product needs repair beyond what is covered under warranty, we will provide parts and service at a reasonable charge.

This warranty gives you, the original purchaser, specific legal rights. You may also have other rights which vary from state to state. Do not return your product until you have received authorization and instruction to do so.

To obtain service, contact us at www.KodiakCanvas.com, or write to:

Kodiak Canvas Customer Service PO Box 762 Layton, UT 84041 USA

Component Check List

Identify all components and make sure they are in good condition and working order.

Description	Quantity
Canvas Wall Enclosure	1
Tent Stakes (large)	4
Tent Stakes (small)	7
Guy-rope (standard)	4
Storage Bag	1
Stake Storage Bag	1
Pocket Organizer	1
Bag Organizer	1

Assembly Instructions

Step 1 – Assemble the tent and awning (sold separately)

Assemble the tent according to the instructions. Assemble the awning, but do not fully extend the adjustable awning poles until after the Wall Enclosure is in place.

Step 2 – Install the Wall Enclosure

Find the three tabs with grommets on the top edge of the Wall Enclosure. Place grommets over the tips of corresponding upright poles (see figure 1). The tabs are placed under the Awning roof.



Figure 1

Secure the Wall Enclosure to the tent body by joining the large hook and loop (similar to Velcro) strips, and tie loops. Secure the top edge of the Wall Enclosure to the awning frame with hook and loop tabs.

Step 3 – Secure the awning roof in place

Place the awning roof over the top of the awning frame. Extend the telescoping awning ridge poles and gables until taut. Secure to the frame with hook and loop tabs. Attach the guy-ropes to the small loops at the side of the awning roof. Secure with large tent stakes.

Step 4 – Secure bottom with stakes

Secure the bottom of the Wall Enclosure with small tent stakes.

Care

• VERY IMPORTANT—Your tent must be completely dry before storage! STORING A WET OR DAMP TENT CAN RUIN IT AND VOID THE WARRANTY.

• To clean tent, hose down with water and wipe with a cloth. Do not use soaps and detergents as they can damage the water-repellant treatment of the canvas.

• Do not spray insecticides or bug repellant directly on the canvas. This may damage the water-repellant treatment.