



ONE Home Collection Reusable Dehumidifier Bag keeps your clothes and your dry goods stay dry. With a quick and easy way to refresh your bag, never worry about moisture getting on your personal belongings.

FEATURES

- Reusable Bag 200g
- Odorless and Non-toxic
- Color Indicator
- Microwavable or Sun Dry

Simply place the Dehumidifier Bag in your drawer, pantry, or hanging next to areas that need to stay dry. Once the print turns pink, untie the bag and place under the sun or microwave at medium heat for 6 minutes or until the print turns blue again. The ONE Reusable Dehumidifier Bag is best to place with your clothes, dry food storage, and more.



18 cm
7in

8.3 cm
3.3in

UPC: 810054152293