



PREMIUM APPLIANCE CLEANER

- Removes Finger Prints, Dirt & Smudges
- Protective Cleaner Spray & Microfiber Cloth
- Safe for all Kitchen Appliances



PREMIUM APPLIANCE CLEANER



Kitchen appliances are constantly being touch causing the surfaces to be filled with unwanted smudges, streaks, and fingerprints. Even when we are not using appliances, dust and dirt can accumulate leaving distracting specks on the screen. ONE Smart CE Gear Premium Appliance Cleaner is the perfect solution to shield, protect and prevent future blemishes. Our cleaning solution is formulated to effectively clean and protect most appliances without leaving streaks or unwanted residue.

The Premium Appliance Cleaner is designed so you always have a cleaning cloth for deeper cleaning. No more smudges, streaks, and fingerprints. By using the premium cleaning solution and our high-density cloth, your kitchen appliances will be back to pristine condition in no time.