
INFLATABLE SCREEN

1: Open the box and take out the screen frame.



2: Spread the movie screen frame and find the fan connection port to the screen frame then connect the fan to it. Find the exhaust vent under the moive screen frame and close the zipper before use fan to inflate



3: The fan connected to the screen and make it expand, after screen frame starting to inflate then let the frame is tilted backwards.



4: Open the projection cloth and lay it on the frame, first attach it to the top of the frame and then stick it to the bottom.



5: After affixing the projection cloth, set it up and then fix the rope of the link frame.

