




HandFan

手风



HF352L

# **HandFan** Mini Handheld Desktop Fan

Thank you for choosing our products.

Please read this instruction manual carefully before use

## **HandFan** Safety guarantee and special design

1. Battery safety design: using PIC (positive temperature coefficient) and CID (current interruption device), Prevent the battery from exploding.
2. Safe design for remote protection, using separate charging protection circuit to prevent overcharging, Over-discharge, over-current, short circuit to ensure life and safety
3. Input and charging safety design; use personal management integrated circuit. Constant current charging design, Ensure safety and explosion protection, extend battery life,
4. Output safety design: using fixed frequency to protect the motor from damage. And guarantee Service life.
5. Creative turbo blades design, strong silent nature wind.
6. Motor lock protection to prevent the motor from burning out when locked.

## **Packing List**

Fan, base, USB cable, manual.

## Basic parameters

Model	HF352L
Speed regulation	4 Speeds
Output	2W
Input	5V/1A
Battery specifications	2000mAh
Battery installation method	Unremovable
Charging time (H)	4h
Size (mm)	145.1 x 68 x 34.8mm
Weight (g)	96.3g
Working time (H)	3-10H,first naturan wind:18H


## How to use

1. Press the power button to turn on first natural wind-second wind-third wind and power off in turn. Long press the power button to turn off the power at any wind mode.
2. Use a USB 5V for charging the fan(On charging: red light on; full charged:green light on; on working:blue light on). 9V,12V fast charger is not compatible.
3. If you store for a long time, please keep 80% of the power.
- 4.First natural wind working mode: stop every 5s for every 5s working.

## Indicator status description

"●" Light/Lights off "○"		
	○	Rest
Press once	● First natural wind	Work
Press once	● Second Wind	Work
Press once	● Third wind	Work
Press once	● Fourth wind	Work
Press once / long press	○	Stop
Steady red light	●	Charge
Steady green light	●	Full charged
Blue light stays on	●	Work

## Key Description



## Attention

1. Do not touch the rotating fan blade with your finger. Children under 10 years old must use the fan under supervision of guardianship.
2. Battery are unremovable, please do not extrude or disassemble to avoid damage.
3. If you need to store the fan for a long time, please charge the battery to 80% and store at dry and ventilated place.
4. Please take care of the fan, any press, falling down and conflicts would cause damage, which will influence its performance.
5. Do not use the fan under environment over 60°C. Do not put the fan into fair, which may lead to explosion.
6. Do not throw away or dispose the fan casually, to avoid environmental pollution.