


Update Wi-Fi firmware

1. Under the situation of TINA2 connected to network, go to Control Panel → Network Settings → Wifi Device OTA



Main
Temperature
Z offset Setting
Wifi network
Language

Control
Show ip
Wifi Device Info
Connect to wifi
Wifi OTA Update

2. If there is no new WIFI firmware, the screen prompts No new firmware found.

OTA UPDATING...
Do ont turn off power
wait a minute
No new firmware found

3. If there is new WIFI firmware, Begin ota updating... will be prompted on the screen.

Wait 1 minute, after the firmware upgrade is complete, the screen will prompt OTA update completed. If the screen prompts Firmware Upgrades Failed or more than 3 minutes, the upgrade does not end, please turn off the printer power, wait 10 seconds, then try again.