


voice caddie B1 User Manual



voice caddie

Basic User Guide [Setting]

▶ External Function and Components





▶ Update and Charging Method

- To update the latest golf course data in your product, please download the Data Manager from www.voicecaddie.com
- Charge by using the exclusive USB cable included.




Basic User Guide [Operation]

▶ Switch ON/OFF



Basic User Guide [Operation]


▶ Menu Guide



* Controlling from sub menu
 Button : Go to next setting or save and return to menu
 Tap : Increment (+1), switch to am/pm, or switch to on/off

Basic User Guide [Operation]

▶ Distance Guide




Distance guide to front or back of green: From distance guide to center, "tap" once to switch between "Center" ▶ "Front" ▶ "Back"




Basic User Guide [Operation]

▶ Start Golf Mode




▶ End Golf Mode



▶ Time display in golf mode
 From sleep state, push button once or tap screen twice to check hole info and time

Basic User Guide [Operation]

▶ Double Green Guide



▶ Measure driving distance

- Start measuring driving distance: Push button from remaining distance guidance page to indicate distance for 3 seconds and notify the start of measuring driving distance
- Complete measuring driving distance : Push button once from remaining distance guidance page to guide driving distance for 3 seconds.



Basic User Guide [Operation]

▶ Automatic recognition of golf course/hole

- In golf mode, on reception of satellite signal, "READY" will appear.
- Golf course is automatically recognized. Distance guide will begin if you move to teeing ground.

▶ Changing Units of Measurement

Continuously push button twice from distance guidance page to switch between meters and yards.

▶ Time Setting

This product automatically sets the accurate time of relevant region from satellite signal. If you want to set time, please start in golf mode outside. You can also manually set time in "TIME" menu.

▶ Sleep Mode

This device automatically converts to sleep mode if it is idle for a certain period of time. To reactivate the device, push button once or tap the screen twice.
 Time to Sleep Mode: Clock mode: 5s / Golf mode: 8s

Guidelines

- The time taken to search satellite from golf mode may vary according to reception conditions (e.g. weather, terrain).
- If in the case the wrong hole is displayed (and will not revert), turn the unit off and on again.
- The product can be used up to 8 hours with one full charging. If satellite reception is not optimal, the battery consumption may drastically increase.
- To increase product usage time, it is recommended to switch on when ready for play.
- Exposing the unit to extreme temperatures for prolonged periods may lead to product damage.

Warranty

- Each Voice Caddie unit is manufactured under strict quality control and inspection guidelines
- In case of defects under normal use, replacements will be provided under warranty guidelines
- Warranty will not cover issues related to misuse or incidental damages
- Customer shall present this warranty and documents related to the Purchase (Receipt) upon request for A/S or Compensation.

Product Name	Voice Caddie	Guarantee Period
Model Name	B1	1 year from product purchase date (6 months for battery and other components)
Purchase Date	MM /DD /YYYY	
Buyer Address		
Name		Phone

voice caddie
 Tel : 888-939-3978
 E-mail : contact@voicecaddie.com
www.voicecaddie.com