

EL1

User Manual




▶ EL1 Components



- 1. Laser light / Objective Lens
- 2. Laser light
- 3. Mode convert button
- 4. Power / Measurement button
- 5. Ocular Lens/ Eyepiece
- 6. Battery insert
- * Package Contents: Laser, Pouch, Battery(CR2) User Manual, Cloth

▶ Laser LCD Window Description



* When icon is displayed on screen, please replace battery.

1. Power On

After inserting the battery, press the power button((b)) to turn on the LCD screen.

2. Mode Conversion

Press the mode button (M) to togale between modes.

Standard Slope Mode (NORMAL) – Slope Pin Mode (PIN)

3. Unit Conversion

Press and hold the mode button (\circledR) for 3 seconds to switch between M (Meters) and Y (Yards)

4. Focus Control


Turn the focus control section of ocular eyepiece to the left and right to adjust the OLED screen clearly.

▶ Slope Mode



* Normal Mode

- Press and hold power button (🖒) for continuous scan to specific target.



* Pin mode

 Provides Slope compensated distance Measurements to the height of the pin from current position

Product Warranty

- This device was produced through strict quality control and thorough inspection, and may be exchanged or reimbursed in accordance with the Fair Trade Commission Notice Consumer Dispute Resolution Criteria.
- If any problem occurs in normal use, the product will be repaired free of charge within the warranty period.
- For after-sales service and damage compensation, please present this warranty and proof of purchase (receipt).

Droduct namo

Productriaine	VOICE CADDIE EL I
Serial Number	
Date of Purchase	
Place of saler	
Contact info of saler	
Purchase's name & contact info	
Warranty Period	One year after the date of purchase, (other components 6 month)
exchange and refund period	Within 30 days of product purchase and unused

VOICE CADDIE EL 1

▶ Precautions

- This device may be affected by the weather such as rain and clouds, and the surrounding environment.
- 2. Depending on your environment and how you use it, battery consumption may increase. 3. Do not use this device for any other purpose such as children's toys.
- 4. If the person's eye is exposed directly to laser irradiation, or exposed to the sun or
- strong light through this device, his/her eyesight may be impaired,
 5. The lens is coated, so care must be taken when cleaning. In order to prevent damage to
 the lens, do not touch the lens directly with fingers and rough material.
- Do not keep this device in hot places such as exposed to direct sunlight, in closed vehicles on hot days, or with heaters.
- The device may be damaged by liquids or other substances.Do not use it an environment where water can come into contact with it, and wipe off any foreign substances immediately.
- Do not randomly modify this device such as dropping, throwing, putting in foreign substances, disassembling, incineration, etc.
 Please use only a dedicated battery.
- 10. Be careful not to open the pouch and drop the product due to strong movement.
- 11. Natural cosmetic deformation and degradation of performance due to normal use and aging are not warranted,

Specification

(1 y = 0.91m)

	(1) - 0.3 111
MODEL	VOICE CADDIE EL1
Key Functions	Slope Normal / Pin Mode, Vibration & Alert, Scan mode
Dimensions / Weight	H 34 x V 67 x L 93mm / 160g(battery Excluded)
Measurement Range	Approx. 5 – 1,000 y
Tolerance	±1 y
Battery	CR2-3V
Country of Origin	China
Importer / Distributor	VC Inc.

► A/S

- Responsible Party U.S Contact Information
- Street Address : 13951 Valley View Ave
- City, State: La Mirada, CA Postal Code: 90638 Country: United States
- Telephone Number: 562-926-3978
- Internet Contact Information: Support@voicecaddie.com

