



RE•vibe™  
User Manual

Visit [fokuslabs.com](http://fokuslabs.com) for how-to videos!

ANTI-DISTRACTION WRISTWEAR

REVIBE

Micro-USB Charging Cord



Programming Tool

Wall Charger

Action Button



Charging Port

# QUICK START GUIDE

**STEP 1:** Charge RE-vibe™ by plugging charging cord into charging port, found on the underside of the plastic piece. A full charge takes about 2 hours.



Plug charging cord into charging port, found on underside of plastic enclosure.



The red light indicates RE-vibe is charging. (During regular use, a flashing red light indicates battery is low.)



The white light indicates RE-vibe is fully charged.

## **Charging Tip:**

Don't charge overnight. Unplug after full charge to maximize battery life. Contact support if sudden decline in battery life is observed.



**STEP 2:** RE-vibe is ready to go!\* (RE-vibe ships from the factory in Mode 1.)

\*Please read these instructions to children before they begin their first task with RE-vibe:

RE-vibe does not 'sense' when you are off-task. When you feel a reminder vibration, ask yourself:

***“Am I doing what I am supposed to be doing?”***

*If you are on task when it vibrates, congratulations! Give yourself a pat on the back and keep up the good work!  
If not, use it as a reminder to get back to work.*

## SWITCHING MODES

Switch to programming mode by using the programming tool to press and HOLD the Action Button for 10 seconds, then release. RE-vibe will give a long vibration, and flash the red and white lights, to indicate you are in programming mode.

Tap the Action Button to toggle through Modes 1-4.  
See chart below for mode descriptions.

After you tap, RE-vibe will give a vibration signal to indicate which mode you have selected (one vibration for Mode 1, two vibrations for Mode 2, etc.). Press and hold for 10 seconds to save your selection.

Note: Once you begin using RE-vibe, each mode will give a variety of different vibration patterns for reminders. These different vibration patterns are to prevent you from getting used to the reminders, and are not indications of which mode you are in.



<b>Setting:</b>	<b>Reminder Frequency:</b>
↓ Mode 1 - Mildly Distracted	About every 10 mins.
↓ Mode 2 - Moderately Distracted	About every 7 mins.
↓ Mode 3 - Significantly Distracted	About every 5 mins.
Mode 4 - Homework Mode	About every 3 mins. After 15 minutes of working, RE-vibe will cue a break by flashing its' lights. Lights will remain flashing during the 5 min. break, then turn off when it's time to go back to work.
U After toggling through modes, RE-vibe will go back to Mode 1 after advancing through Mode 4.	

## **PUTTING RE-VIBE TO SLEEP - TURNING ON/OFF**

Take off RE-vibe, re-velcro the strap, and place it on a table. It will fall asleep automatically within 20 minutes. RE-vibe will wake up automatically when it is moved.

Vibrations from movement or loud sounds (highways, dogs barking, nearby trains, etc.) can wake up RE-vibe.

To manually turn RE-vibe off, quickly double tap the Action Button. RE-vibe will vibrate twice to indicate it is turned off. It must be manually turned back on in order for it to function. To manually turn RE-vibe back on, double tap the Action Button again. RE-vibe will run through a series of vibrations (more than two) to indicate it is on.

## **CLEANING RE-vibe**

Wipe plastic enclosure with a clean cloth.

To wash wristband, remove from plastic enclosure and hand wash in warm soapy water. Allow it to air dry completely before replacing the plastic enclosure.

RE-vibe is SPLASH RESISTANT, NOT WATERPROOF!

Washing your hands while wearing RE-vibe is ok, but please do not swim, bathe, or submerge RE-vibe in water.

## Limited One Year Warranty

### What is Covered

This warranty covers any defects in materials or workmanship in your RE-vibe™.

### How Long Coverage Lasts

This warranty runs for one year from the date you purchase your RE-vibe™.

### What is not Covered

Batteries, or any problem that is caused by abuse, misuse or an act of God (such as a flood) are not covered. Also, consequential and incidental damages are not recoverable under this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

### What FokusLabs Will Do

FokusLabs will repair or replace any RE-vibe™ that proves to be defective in materials or workmanship.

### How to Get Service

In order to be eligible for service under this warranty you MUST provide a copy of your original purchase receipt.

If something goes wrong with your RE-vibe™, please contact customer support immediately at 919-813-0427 or Support@FokusLabs.com. Subsequently, an RMA (Return Merchandise Authorization) number and return form may be issued to you. If this occurs you can then send your RE-vibe™ postage paid with a completed return form including RMA number to:

FokusLabs Behavioral Solutions, Inc.  
3331 Heritage Trade Drive Suite 101  
Wake Forest, NC 27587

If the RE-vibe™ you return to us is found to be defective in materials or workmanship during the one-year warranty period, we will repair or replace the product at no expense to you. We will send you a replacement product at the address you specify to us (US only). FokusLabs will provide standard shipping for all units found to be defective under the aforementioned conditions of 'defective materials or workmanship'.

### How State Law Applies

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**Disclaimer of Medical Liability.** RE-vibe™ is not a medical device and is not intended to diagnose, treat, cure or prevent any disease or condition, nor is it a substitute for any professional medical advice, diagnosis or treatment. Accordingly, FokusLabs does not provide any warranty or representation with respect to the merchantability, fitness or suitability of RE-vibe™ for treating any medical condition. Because RE-vibe™ is not a medical device, it has not been manufactured in accordance with quality standards that may be necessary for materials intended for use in medical device applications and FokusLabs has not sought or received any rulings from the U.S. Food and Drug Administration as to the safety or effectiveness of the RE-vibe™ for medical purposes. Purchasers of the RE-vibe™ proposing to evaluate or use the RE-vibe™ for a medical purpose should rely upon qualified medical professionals before doing so. If you have a medical or heart condition, consult your doctor before using the RE-vibe™. If you experience a medical emergency, stop using RE-vibe™ and consult with a medical professional.

**Skin Irritation.** If you notice any signs of skin redness, swelling, itchiness, or other skin irritation from using your wristband, please discontinue. Continued use, even after symptoms subside, may result in renewed or increased irritation. If symptoms persist, consult your doctor. Do not wear your RE-vibe™ wristband more than twelve consecutive hours. Doing so can lead to skin irritation or chafing. Prolonged contact may contribute to skin irritation or allergies in some users.

**Product Risks.** RE-vibe™ contains electrical equipment that could cause injury if not handled properly. This product is not a toy and should be used under adult guidance. Do not allow children or pets to play with the product. The product includes/contains small components that can be a choking hazard. Do not use your RE-vibe™ product if the unit is cracked or damaged. Substances in this product and its battery may harm the environment or cause injury if handled and/or disposed of improperly. Do not dispose of your RE-vibe™ product in a fire. The battery could explode. Be sure to remove from person/charger and cease use if your RE-vibe™ product feels warm or hot to the touch and contact customer service immediately, at 919-813-0427 or Support@FokusLabs.com

**Prohibited Uses.** Do not submerge your RE-vibe™ in water. Do not expose your RE-vibe™ to extremely high or low temperatures. Do not leave your RE-vibe™ in direct sunlight for an extended period of time or in a hot vehicle as this could cause damage to the components. Take care not to damage or puncture your RE-vibe™. Do not place your RE-vibe™ product in a dishwasher, washing machine, or dryer. Do not use your RE-vibe™ product in a sauna or steam room. Do not use abrasive cleaners to clean your RE-vibe™ product. Do not insert any objects into the micro-USB charging port or the programming ports, other than the provided micro-USB charging accessories and plastic programming tools, respectively.

**Limitation of Damages.** EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, FOKUSLABS, INC. SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF EXPRESS OR IMPLIED WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, EVEN IF FOKUSLABS, INC. HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some jurisdictions do not allow the exclusion or limitation of special, indirect, incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Follow us on social media and be the first to know about our exciting updates ... like our hot new colors!

 /FokusLabsREvibe

 @fokuslabs

Questions, Concerns, Feedback?  
support@fokuslabs.com  
919-813-0427

SHOP OUR FULL SELECTION OF **MIX & MATCH** WRISTBANDS at fokuslabs.com!



 FOKUSLABS