



WINDING THE MAINSPRING

Automatic winding watch can also be hand wound by turning the crown clockwise in the “N” position. Wind 15-20 times and it will start to move naturally after shaking slightly.

SETTING THE TIME

1. Pull the crown out to the position 2.
2. Turn the crown to set hour and minute hands.
3. After the time has been set, push the crown back to the normal position

SETTING THE DATE

1. Pull the crown out to the position 1.
2. Turn the crown counter-clockwise to set the date.
3. After the date has been set, push the crown back to the normal position.

* Do not set the date between 9:00PM and 1:00AM. Otherwise, the day may not change properly. If it is necessary to set the date during that time period, first change the time to any time outside it, set the date and then reset the correct time.