


Test Mode Makes this Device Audible!

This is the unit's test button. If pressed, the device starts emitting a buzzing/clicking sound that you can hear. The unit **will no longer** repel when on this setting; the purpose of this button is to allow you to hear a representation of the device in repelling mode.

If the device is **constantly activated and beeping**, this means the unit is in *test mode*. To return the unit into the *standard repelling mode* simply press the test button. When you can only hear the device clicking occasionally, you know the unit is in proper repelling mode.



TEST MODE - ON
(Not Repelling)


TEST



DOWN

STANDARD REPELLING
TEST MODE - OFF
(Repelling)

TEST



UP

Again, the unit will **not** repel animals when it is in *test mode*.

This is because the test mode changes the frequencies, taking the unit **out of the animal-repulsing frequencies** and into human hearing range.