

CLEANRTH

ADVANCED

Ultrasonic Bird Repeller

CLEANRTH

ADVANCED

Ultrasonic Bird Repeller

We Care About Your Results

Hi, everyone, this is Ron with Cleanrth Products & we are dedicated to positive bird-repelling results.

If for some reason your results are not met at around the 16-20 day mark, please take the time to Contact Us.

We will move to a "Stage 2" worth of help/repelling your bird pest issue.

As a business owner, I understand the frustration of pesky bird problems & I wanted to let you know that we're here to help you when a tough problem comes along.

We Have Solutions For the Real Tough Pesky Bird Issues!

Best Ways to Contact Us

1. If Ordered Online, it's **"BEST"** to **Contact Us** via the **website** you **ordered from** (e.g., Amazon, Walmart, eBay, etc.)
2. Company E-mail: info@cleanrth.com
3. By Phone: Local 1-480-255-5113 or Toll Free 1-855-707-7075

QUICK - GUIDE





Customers have reported success repelling:



We care about your results!

Recommended Settings



Step 1 Remove your device and power adaptor from the box.

Step 2 Open the back of the unit and insert the plug end into the 9V DC Input jack located inside the unit. Plug the adaptor into a standard US120V electrical outlet (that is protected from the rain). You can also power the unit by using four C Alkaline batteries (not included).

Step 3 Choose a nearby spot to set your unit that directly faces the most open area around the Bird Problem. The unit needs to sense bird movement and body heat in order to activate.

Step 4 Set all the Switches using our recommended settings shown below.

Strobe Light: Set this to the middle - **Sensor** - option. The strobe light will only activate when the Infrared Sensor detects body heat; this is a better way to suddenly startle birds than letting the lights flash continuously.

Sound/Ultrasonic: Set this to the middle - **Sensor** - option. The speakers will only activate when the Infrared Sensor detects body heat; this is a better way to suddenly startle birds than letting the lights flash continuously.

Sonic Frequency: Slide the switch to the left to **Low (Sonic/Audible)**. Allow eight days at this frequency then refer to:

Running the Bird Repelling Routine & What To Expect

Sensitivity: Slide the switch to **High** to set sensitivity strength at maximum.

Running the Bird Repelling Routine & What To Expect

- 1) Once set up & turned on, please allow 8 days worth of repelling in 1 spot.
- 2) Use the 8th day as a check point. Do you still see bird activity on this day? Has the issue diminished at all? If the problem has improved; great, please continue to use the device in its current settings.
- 3) If the bird problem still heavily exists, it's time to make a change. Please slide the Sonic Frequency Switch Halfway Up or All the way to High. After making these changes, please allow another 8 days of repelling.
- 4) At this point you should be 16 Days in worth of repelling. Has the issue diminished? If not! Then it's time for us to help. Please Contact Us and we will move to what we like to call our Stage II worth of help: Free of Charge.

Helpful Hints:

- The idea is to give the unit the best angle for Detection so it can Activate when a Bird intrudes into the area. You might find yourself having to make a few adjustments to get it in the perfect spot.
- Repelling birds is all about Scaring, Startling, and making the intruding birds Uncomfortable. Change in Repelling Power, Volume, or Angles can be Key for Tough Issues.

If your Problem still persists after the 16-20 day mark. Please Contact us as we will Move to a Stage 2 worth of Help/Repelling

If Ordered Online, it's "BEST" to Contact Us via the website you ordered from (e.g., Amazon, Walmart, eBay, etc.)

E-mail: info@cleanrth.com or Phone: 480-255-5113