bouncepad®

Counter
Assembly Instructions

Tools Required:

- Socket Driver

In the Box

- Tablet Set-up Kit
- Fixings Kit
- Faceplate
- Case
- Desk Mounting Arm
- Freestanding Base
- Pair of Keys

Fixings List

'Mounting Arm Box' includes:

- 1x T20 Pin Torx Driver Bit
- 4x M4 Split Washer
- 4x M4x20mm Buttonhead screw
- 1x Case Washer

'Freestanding Base Box' includes:

- 4x M4x12mm Buttonhead screw
- 4x M4 Split Washer

* Due to the modular nature of our product range you may receive additional fixings in the fixings kit

---

1 Locate & secure the Flex Mounting Arm to the Freestanding Base.

Tighten screw(s) using hand tools, using electric tools may damage your Bouncepad.

- M4 Split Washer
- M4x12mm Buttonhead screw
- T20 Pin Torx Driver Bit

---

2 Attach the Bouncepad Case to its Mounting Arm. Take care to ensure correct & full thread engagement.

Tighten screw(s) using hand tools, using electric tools may damage your Bouncepad.

- T20 Pin Torx Driver Bit
- M4x20mm Buttonhead screw
- M4 Split Washer
- Case Washer

3 Unlock & remove the Faceplate from the Bouncepad Case.

4 Install the Tablet Setup Kit. Each kit is specific per tablet device and Bouncepad Case.

- 4x Tablet Supports
- 1x Cable Clip
- 4x Corner Pieces

**5** Feed the tablet cable through the Bouncepad Case & mounting arm

5 Place the tablet into the Case and connect to power.

6 Locate and lock the Faceplate onto the Bouncepad Case.

7 Installation is now complete.

Key number here

*We recommend recording the key number so you can purchase additional keys in the future.