





# Монтажни схеми BENTOBAR +

Ideal situation:



① Possible problems when nailing & concrete pouring





\* Sealing bar out of centre :  
risk of cracking the wall  
upon expansion

\* Concrete can go underneath  
the sealing bar when pouring  
fresh concrete

→ possible gap → no perfect  
sealing

# Монтажни схеми BENTOBAR +

## ② Fixation by gluing



## ③ Fixation by wire mesh

