



# DOUBLE SPLICE TAPE

Splicetronics Solutions

Part (reel)	Dimensions (pc)	Package
DSJL08 (8mm)	36mm x 4.8mm/7.6mm	250pcs/box
DSJL12 (12mm)	36mm x 11.6mm/8.8mm	250pcs/box
DSJL16 (16mm)	36mm x 15.6mm/12.8mm	250pcs/box
DSJL24 (24mm)	36mm x 23.6mm/20.8mm	250pcs/box



## APPLICATION

- Ⓢ Strips of silver aluminum foil tape with a blue PET strip and plastic jig pins piece
- Ⓢ Possible to use without the splice tool and clip
- Ⓢ 32mm-44mm available upon request

## ADVANTAGES

- Ⓢ Necessary for Fuji machines with an intelligent feeder
- Ⓢ The silver strip allows the sensor to detect the splice
- Ⓢ Jig pins included for easy alignment

## INSTRUCTIONS

- Ⓢ Use the cutting tool to accurately cut the carrier tapes.
- Ⓢ Hold the splice tape (face down/Arrow>).
- Ⓢ Remove the release liner to reveal the adhesive side.
- Ⓢ Place the cut carrier tapes (cover tape down) on the alignment jig pins.
- Ⓢ Fold over the second strip to the underside of the carrier tape and press firmly.
- Ⓢ Remove the black alignment jig pins piece.
- Ⓢ Remove and discard the clear plastic cover to complete the splice.

