(Brey KRAUSE)


BREY-KRAUSE MANUFACTURING 1209 W. LEHIGH ST., BETHLEHEM, PA 18018 PHONE: 610-867-1401 FAX: 610-866-1433

www.breykrause.com

Brey-Krause Mfg. reserves the right to make changes in design and/or materials without formal notice and without incurring obligation.

TECHNICAL DATA SHEET L-1211-LB

4 STEP DOCK LADDER, FRONT MOUNT 6"€ UPPER RAILS, DETACHABLE FLANGE



В


 \exists


ΪÜ

L-1211-LB


TECH_DATA

4/6/2022





TO THE DOCK IS NOT INCLUDED.



Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	L-1204-LB	4 STEP LOWER LADDER
2	2	L-1210-03-LB	6" C/L UPPER RAIL, DETACHABLE
3	1	L-1208-LB	LOWER LADDER MOUNTING KIT
4	1	L-1209-LB	UPPER RAIL MOUNTING KIT

INSTALATION:

- 1) Bolt the upper mounting flanges to the upper hand rails, then bolt the assembled hand rails to the lower ladder, position the ladder in the desired location on the dock. Slide the slip supports onto the lower ladder, check ladder | The ladder is not to be used as a mooring point for boats or personal squareness and mark the screw hole positions for the slip supports.
- 2) Drill and mount the slip supports (Item 3) to the dock, assuring the proper location. Mount (Item 3) short side up for easier fastener installation. Slide the ladder onto the slip supports, check location and assure the ladder is plumb.
- 3) Mark, drill and mount the upper hand rail flanges. Tighten all fasteners.

OPERATION:

Only one person at a time should use the ladder.

watercraft.

The mounting bolts used to secure the ladder flanges should be inspected periodically for tightness.

Assembled Ladder Weight: 35 Lbs.