


morphy richards

Wall Fan

Vento **WF**



Please read and keep these instructions



5year
guarantee
on
MOTOR

Getting the best from your
new Wall fan

2year
guarantee
2 años de garantía (2 años de garantía)

www.morphyrichards.co.uk
www.morphyrichardsindia.com

Caution:

Please read these instructions carefully before installing & operating the fan.

Warning:


1. Do not leave the running fan unattended.
2. Keep electrical appliances out of reach from children and unwell persons. Do not let them use the appliances without supervision.
3. If the supply cord is damaged, it must be replaced by any Morphy Richards customer care center in order to avoid any hazard.
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

5. Children should be supervised to ensure that they do not play with the appliance.

Rules for Safe Operation:

1. Never insert fingers, pencils, or any other object through the grill when fan is running.
2. Disconnect fan when moving from one location to another.
3. Disconnect fan when removing grills for cleaning.
4. Be sure fan is on a stable surface when operating to avoid overturning.
5. DO NOT use fan near window, rain may create electrical hazard.
6. For indoor use only.

Know your Wall Fan:



Assembly of Base:

1. Detach the screw from base enclosure of the fan.
2. Match the locking tab to base enclosure and click into position.
3. Tighten the screw in the base to secure the fan to the base enclosure.




Assembly of Blade & Grills:

1. Remove the spinner and the plastic nut from the front side of the motor. Fix the

rear grill to the motor & tighten the plastic nut again. (Fig.1)

2. Discard PVC sleeve on shaft. Insert the blade into shaft, make sure the stopper pin is fitted into groove of the blade. Turn the spinner counter clockwise to tighten the blade. (Fig.2)

3. Fix both grills with plastic rim and then use screwdriver to tighten the locking screw. (Fig.3)



Operating Instructions:

1. MOUNTING ON THE WALL

Secure the supplied bracket (A) on the wall by using wooden screw or plastic screw, make sure the wider opening should be upward. Insert the hook of the wall fan into the bracket slot.

2. SPEED ADJUSTMENT

Switch on/off the fan and adjust to the desired speed by pulling the pull switch (B).




- 0---Stop, 1---Lower,
- 2---Medium, 3---High

3. OSCILLATION CONTROL

Adjust the position of the oscillation by pull switch (C).

4. TO ADJUST THE WIND DIRECTION

Push the guard lightly to the desired or down direction.



Maintenance Instructions:

The fan requires little maintenance. Do not try to fix it by yourself. Call any Morphy Richards customer care center.

1. Before cleaning and assembling, do not plug the pins into the socket.
2. To ensure adequate air circulation to the motor, keep vents at the rear of the motor free of dust. Do not disassemble the fan to remove dust.
3. Please wipe the exterior parts with a soft cloth soaking a mild detergent.
4. Do not use any abrasive detergent or solvents to avoid scratching the surface.
5. Do not use of the following as a cleaner: gasoline, thinner, etc.

6. Do not allow water or any other liquid into the motor housing or interior parts.

Cleaning:

1. Be sure to unplug from the electrical supply source before cleaning.
2. Plastic parts should be cleaned with a soft cloth moistened with mild soap. Thoroughly remove soap film with dry cloth.

Technical Data:

Power Supply	: 230V ~ 50Hz
Wattage	: 55W
RPM	: 1300

Morphy Richards products are intended for household use only

Morphy Richards has a policy of continuous improvement in product quality and design. The Company, therefore, reserves the right to change the specification of its models at any time.

Products & parts are indicative only, the actual product may differ.

morphy richards

Morphy Richards Ltd, Mexborough,
South Yorkshire, England, S64 8AJ


morphyrichards

Wall Fan

Vento ^{WF}



कृपया इन निर्देशों को पढ़ें व रखें



५ साल
की गारंटी
मोटर पर

२ साल
की गारंटी
2 años de garantía (2 años de garantía)

अपने नये दीवार पंखें से
सर्वश्रेष्ठ पायें

www.morphyrichards.co.uk
www.morphyrichardsindia.com

सावधानियां:

पंखे को लगाने और चलाने से पहले कृपया इन निर्देशों को ध्यानपूर्वक पढ़ें

चेतावनी:


1. बिना निगरानी के पंखे को चलता हुआ न छोड़ें.
2. बिजली के उपकरणों को कृपया बच्चों व बीमार लोगों की पहुंच से दूर रखें. निगरानी के बिना उन्हें उपकरणों का उपयोग न करने दें.
3. यदि सप्लाई कॉर्ड क्षतिग्रस्त हो गया है तो किसी भी जोखिम से बचने के लिए यह ज़रूरी है कि उसे सिर्फ मॉरफी रिचर्ड्स कस्टमर केयर सेंटर द्वारा ही बदला जाये.
4. यह उपकरण ऐसे लोगों (बच्चों सहित) द्वारा प्रयोग के लिए नहीं है जिनकी शारीरिक, संवेदना या मानसिक क्षमता सीमित है या जिन्हें अनुभव व जानकारी की कमी है, बशर्ते उन्हें उनकी सुरक्षा के लिए जिम्मेदार किसी व्यक्ति द्वारा उपकरण के प्रयोग के बारे में जानकारी या निर्देश दिये जायें.

६. बच्चों पर नज़र रखनी चाहिए ताकि यह सुनिश्चित हो सके कि वे उपकरण के साथ खेलें नहीं.

सुरक्षित संचालन के नियम :

1. जिस समय पंखा चल रहा हो उस समय कभी भी उंगली, पेंसिल या अन्य कोई वस्तु उसमें न डालें.
2. पंखे को एक स्थान से दूसरे स्थान तक ले जाते समय उसे डिस्कनेक्ट कर लें.
3. सफाई के लिए जब, ग्रिल उतारते समय पंखे को डिस्कनेक्ट कर लें.
4. पंखे को किसी स्थिर सतह पर रखें ताकि चलते समय ओवरटर्निंग से बचा जा सके.
5. पंखे को खिड़की में उपयोग न करें, बारिश के कारण विद्युतीय जोखिम हो सकता है.
६. सिर्फ घर के अंदर उपयोग करने के लिए.

अपने दीवार पंखे को जानिये






बेस की असेंबली:

1. पंखे के बेस एनक्लोजर से स्कू अलग करें.
2. लॉकिंग टैब को बेस एनक्लोजर से मैच करें और पोजीशन में क्लिक करें.
3. पंखे को बेस एनक्लोजर में जमाने के लिए बेस में स्कू कस दें.

ब्लेड व ग्रिल्स की असेंबली:

1. मोटर के सामने वाले हिस्से से स्पिनर और प्लास्टिक नट निकाल दें. मोटर का पिछला ग्रिल मोटर में फिक्स



कर दें फिर प्लास्टिक नट को वापस कस दें (चित्र १)

2. शाफ्ट पर पीवीसी निकाल दें, ब्लेड को शाफ्ट में डालें, सुनिश्चित करें कि स्टॉपर पिन ब्लेड के खांचे में फिट हो गया है. ब्लेड को कसने के लिए स्पिनर काउंटर को घड़ी की दिशा में घुमाएं (चित्र २)
3. दोनों ग्रिल को प्लास्टिक रिम के साथ फिक्स कर दें और फिर लॉकिंग स्कू को कसने के लिए स्कू ड्राइवर का उपयोग करें (चित्र ३)

संचालन के लिए निर्देश:

1. दीवार पर लगाना

दिये गये ब्रैकेट (A) को लकड़ी के स्कू या प्लास्टिक के स्कू का उपयोग करते हुए दीवार पर मजबूती से लगा दें, यह सुनिश्चित करें कि चौड़ा मुख ऊपर की तरफ हो, दीवार पंखे के हुक को ब्रैकेट के खांचे में डाल दें.

2. स्पीड एडजस्ट करना

पुल स्विच (B) को खींच कर पंखे को ऑन/ऑफ करें और मनपसंद स्पीड पायें.

0--स्टॉप १--लोअर




२--मीडियम ३--हाई

3. ऑसिलेशन कंट्रोल

पुल स्विच (C) द्वारा ऑसिलेशन की स्थिति को एडजस्ट करें.

4. हवा की दिशा को एडजस्ट करना

मनपसंद या नीचे की दिशा में लाने के लिए गार्ड को हल्के से दबायें.



रखरखाव के लिए निर्देश:

पंखे को धोड़े रखरखाव की ज़रूरत होती है. इसे खुद से फिक्स करने की कोशिश न करें. इसके लिए मॉरफी रिचर्ड्स कस्टमर केयर सेंटर पर कॉल करें.

1. सफाई व असेंबली करने से पहले पिन्स को सॉकेट में प्लग न करें.
2. मोटर में हवा के समुचित सर्कुलेशन सुनिश्चित करने के लिए मोटर हाउसिंग के पिछले हिस्से के वेंट को धूल, गर्द आदि से साफ रखें. प्लग निकाले बिना इन वेंटों की सफाई करने के लिए किसी वैक्यूम क्लीनर का प्रयोग नहीं किया जा सकता.
3. किसी हल्के डिटर्जेंट में एक नरम कपड़े को भिगोकर उससे बाहरी हिस्से को पोंछें.
4. सतह पर खरोंच न आये, इसके लिए कोई खुरदुरे डिटर्जेंट या सॉल्वेंट का प्रयोग न करें.
5. क्लीनर के रूप में निम्नलिखित का प्रयोग न करें:
गैसोलीन, थिनर इत्यादि.
6. मोटर हाउसिंग या पंखे के अंदरूनी हिस्सों में पानी या अन्य किसी प्रकार के द्रव्य को जाने न दें.

सफाई:

1. सुनिश्चित करें कि क्लीनिंग से पहले पंखे का प्लग निकला हुआ है.
2. प्लास्टिक हिस्सों को किसी हल्के डिटर्जेंट में एक नरम कपड़े को भिगोकर साफ करना चाहिए. साबुन को सूखे कपड़े से अच्छी तरह से निकालें.

तकनीकी आंकड़े :

Power Supply : 230V ~ 50Hz
Wattage : 55W
RPM : 1300

मॉरफी रिचर्ड्स के उत्पाद सिर्फ घरेलू उपयोगों के लिए बने हैं

मॉरफी रिचर्ड्स की नीति उत्पादों की गुणवत्ता और डिज़ाइन में सतत सुधार करते रहने की है. इसलिए कम्पनी के पास अपने मॉडलों के विशिष्टीकरण में कभी भी परिवर्तन करने का अधिकार सुरक्षित है.

उत्पाद व पुर्जें सिर्फ सांकेतिक हैं, वास्तविक उत्पाद इनसे अलग हो सकते हैं.

morphy richards

मॉरफी रिचर्ड्स लिमिटेड, मेक्सबॉरो
साउथ यॉर्कशायर, इंग्लैंड, एस६४ ८एजे