



使用说明书 (Operating instructions manual)

(Tent on the roof, home on the road)

如何安装 (How to install)

1、配件展示 (Attached parts and tools)



支撑杆 (support rod)

2.3 米伸缩梯子 (2.3m telescopic ladder)

工具包 (Toolkit):

垫片 (hole patch)

螺栓 (Bolt)

螺母 (Nut)

扳手 (Spanner)

在安装帐篷之前要先安装好车顶横杆或者是车顶平台。**(Install the roof bar or roof platform before installing the tent)**








2、安装方形垫片，插入卡槽 (Combine the hole patch and nuts, then insert into the card slot.)





3、放入垫片,螺帽固定 (Put in the hole patch and fix it with nuts.)



如何打开 (How to open)

1 松开安全卡扣 (Unlock safety snaps)



2、向上抬上帐篷的一侧 (Open one side of the tent)



3 向上抬起帐篷另一侧 (Open the other side of the tent)



4 帐篷搭建完成 (Complete tent set up)



如何收纳 (How to storage)

- 1、取下遮阳帘支撑杆 (Remove support rods)



2、拉带拉下一头, 先用卡扣大概固定 (Use a long tape on one side to pull the tent down and then secure this

side roughly with safety snaps.)



3、拉带拉下另一头，整理收纳布套 (Use a long tape to pull down the other side and then tidy up the tent cloth.)



4.用卡扣固定，收纳完成 (Secure the sides with safety snaps to complete the storage.)

