

OontZ

SUP Mount & Bracket

for OontZ Bluetooth Speakers

User Guide

Attaching the OontZ Speaker Bracket & Mount to the OontZ Angle 3 ULTRA SUP Special Edition Speaker. Designed specially for the OontZ Angle 3 ULTRA SUP Special Edition Speaker.

1 Assemble the OontZ SUP Mount and Base to your Paddleboard, Surfboard or other smooth surface.

- Adheres best to smooth surfaces such as epoxy, ABS and fiberglass.
- Rough surfaces or glass may not adhere firmly and cause the mount with the speaker attached to fall off.

- 1) Peel off the yellow cover on one side of the 3M tape.
- 2) Press the side of the 3M tape with the yellow cover removed to the bottom of the OontZ SUP Mount and Base.
- 3) Peel off the red cover from the 3M Tape.
- 4) Place the OontZ SUP Mount and Base on the dry, smooth surface and press down to adhere the mount to the surface.



Note: After placing the OontZ SUP Mount on the surface, it is recommended to keep the surface dry and let the 3M tape adhere to the surface for a minimum of 20 minutes before use.

2 Attach the OontZ SUP Mount to the OontZ Speaker Bracket.

- 1) Place the bottom of the OontZ Speaker Bracket into the slots of the OontZ SUP Mount.
- 2) Insert the Thumb Screw into the OontZ SUP Mount.
- 3) Tighten the Thumb Screw to secure the bracket to the mount. When tightened the speaker will stay in position.



3 Loosen the adjustment knob on the back of the bracket until the bracket is wide enough to fit on the bottom of the speaker.



4 While holding the assembled Oontz Bracket and Mount, place the bottom of the speaker into the bracket. The curved portion of the bracket should fit to the curved bottom of the speaker.

Note: There will be a small gap between the bottom of the speaker and the top flat surface of the bracket.



5 Turn the adjustment knob on the side of the bracket until the bracket firmly clamps to the speaker.



Note: Do not over tighten as it may damage the bracket.

- 6** The assembled OontZ SUP Bracket, Mount and Speaker can be detached from the OontZ SUP Mount Base on your Paddleboard, Surfboard, etc.

Firmly press together the clips on the side of the OontZ SUP Mount and slide the OontZ SUP Mount out of the OontZ SUP Mount Base.



Note: If using in salt water environments, after use rinse with fresh water, wipe off the water and place in a dry place. This will keep the speaker, bracket & mount from rusting over time.

Customer Support

If you have a question about your OontZ Speaker Bracket or Clamp Mount, our Customer Service Team wants to assist you.

Contact us at:

TheOontZ.com/support

and fill in our customer service form