

CARE AND MAINTENANCE LAMINATE FLOORING

Room Conditions

Timber likes pleasant room conditions similar to humans; a room temperature of 20°C and humidity of about 50%. A humidity controller may be required. All rooms, which have timber flooring, should ideally be maintained at the above.

LAMINATE FLOORING

Laminate floors are low maintenance products. Laminate flooring does not require any special initial treatment. To prolong the lifespan of the floor it is important to use the recommended maintenance products below as it provides ongoing protection to the floor surface.

Laminate floors have a level of water resistance, however damage can occur if spillages of liquid onto the surface are not wiped up immediately. If there are other building works taking place after installation the floor should be covered to protect the finish. Please see the reverse of each Woca product for full usage instructions. There are also detailed video instructions available at www.wocadenmark.com/video

CLEAN (REGULARLY)



Master Cleaner
Avg. Coverage: 400m²/L

Effectively removes everyday dirt and grime as well as making the surface stronger and more resistant to liquid spillages. As the cleaner leaves a thin smooth film layer, the floor will start to withstand everyday dirt.

REJUVENATE (AS REQUIRED)



Master Care
Avg. Coverage: 60m²/L



Intensive wood cleaner
Avg. Coverage: 200-300m²/L

Helps to reduce the visibility of small scratches, increases the resistance of the surface and provides effective protection against wear. This extends the lifetime of the surface. The product can be used as required because it does not build up a thick coating.

We recommend using Master Cleaner for regular cleaning of your laminate floor. Woca Master Care is to be used when your floor is in need of refresher treatment. Intensive cleaner should be used for deep cleaning prior to use of Master Care.

Protecting your floor

To preserve quality and beauty of your floor the following guidelines should be followed.

- Use protective pads and castor cups under chairs and furniture legs. Use good quality polycarbonate mats under wheeled office chairs.
- We recommend that good quality entrance barrier mats are used at all external entrances to the flooring to collect grit and moisture from the underside of footwear.
- Never use a rubber mat, with Styrofoam or plastic backing.
- For moving heavy furniture place a piece of carpet face down between the legs and the flooring and pull on the carpet to move the furniture.
- We would advise that during installation / other building works that the floor is covered with a heavy duty breathable floor protection roll / sheets to protect the floor.
- Do not apply adhesive / decorators tape directly to the floor.

In the event of a proven manufacturing defect, the companies or sellers total liability shall under no circumstances exceed the value of the defective product. The company or seller shall not in any way be responsible for any additional consequential costs or losses. If you are unclear regarding any of the above instructions, contact your local supplier.