


Easy Centre Door Knob

M220 Range



Plain and simple styling, a smaller size knob making it easy to blend into its surroundings and easy to clean. Traditionally fitted to the centre of front doors to pull them closed on departing the house. Can be used for this purpose as it is supplied with a substantial fixing or just added to the front door as a charming decorative design feature. Comes with a 10 year mechanical guarantee.

