



Wireless Motion Sensor
PS2 User Manual

Welcome

Thank you for purchasing Xodo Smart home products!

We are committed to brining you excellence. Xodo smart home technology products are convenient, make your life more comfortable and provide a more dynamic lifestyle.

Your new PS2 is a great security feature alerting you if there is detected motion in a specified area.

General Notice

Always make sure to follow safety instructions.

- Do not use products if they have become damaged.
- Follow instructions and only operate products in a safe environment.
- Do not operate electronics in wet conditions. Doing so may cause property damage, bodily harm or electrocution.
- Do not disassemble or alter the product. Doing so will void the warranty.

Table of Contents

Package Contents ————————————————————————————————————	1
Specifications ————————————————————————————————————	2
nstallation of Wireless Motion Sensor ————————————————————————————————————	3
Xodo Smart App ——————————————————————————————————	4
Configure the Wireless Motion Sensor Settings ————————————————————————————————————	7
Link Alexa	8
Customer Service and Tech Support ————————————————————————————————————	10

What's included in the box


You will find the following contents included to help you get started:



XODO*

Modes Motion Sensor
PS2 User Manual

Wireless Motion Sensor



User Manual



Bracket

Mounting Screw Set

Product Features

- Instant Alerts to your smart phone.
- Power Switch.
- Remote Monitoring.

Wireless Motion Sensor PS2

Battery Voltage: 9V 6F22 Standby Current: ≤35uA Alarm Current: ≤45mA Wireless Frequency: 433MHz Control Range: < 250 Feet Detection Range: < 25 Feet Shell switch CGOX Indicator Light Power Button Sensor Battery bay

Power Button — Switch power on/off. Shell switch — Press to open the case. Indicator Light

Red light ON: Sensor detecting movement.

Installation of Wireless Motion Sensor

- 1. Install the arm to the bracket.
- 2. Install the bracket where you want to install.





3. Install the base.

4. Adjust the angle you want.





Download and Install the Xodo Smart APP

Download and install the APP. It can be also be found by searching "XODO Smart" by Contixo Inc. in the App Store (for IOS) or Google Play Store (for Android).







Xodo Smart

Open the APP

The welcome screen will appear and then you will be asked to login or register a profile. Register an account by entering your email address and setting up a profile or logging in with an existing account.







Adding PS2

Turn on your PS2 Wireless Motion Sensor. Select "SA2" in app, then click "Accessories". In the "Accessories" page, click "Quick add" and move in front of the PS2 Wireless Motion Sensor, the SA2 Smart Alarm Gateway will make a prompt. Click "Confirm", your PS2 Wireless Motion Sensor is now ready to work. (The XODO PS2 Wireless Motion Sensor can only work with XODO SA2 Smart Alarm Gateway.)










Wireless Motion Sensor Home Screen

The home screen will show the live Wireless Motion Sensor status.

- 1. Press the "Click to view more" button to view the alarm history.
- 2. Press the " or " button to set the Wireless Motion Sensor alarm mode.







Configure the Wireless Motion Sensor Settings


Different features can be adjusted from the menu button on the upper right hand button " on the APP.

- 1. Device Name can be changed as desired.
- 2. Device information can check the information of the Wireless Motion Sensor.
- Tap-to-Run and Automation allows to check the Smart Automation your device linked with.
- Supported Third-Party Control provides the information about how to connect your device to Amazon Alexa.
- 5. Add Members to be able to control the device in the Share Device setting.
- 6. FAQ & Feedback allows users to report issues and get help.
- Add to Home Screen allows you to add the Wireless Motion Sensor to the home screen of your smartphone.
- Remove device will remove the Wireless Motion Sensor from the Xodo Smart app and remove pairing. This is necessary if pairing with a new device.
- Restore Factory Defaults allows to reset the Wireless Motion Sensor to factory setting.



Link Xodo Smart account to Alexa

- 1. Download the free Alexa app from the Amazon Appstore, Google Play, or the Apple App Store.
- 2. Open Alexa app to home screen
- 3. In upper left hand corner open the menu.
- 4. Next click on "Skills & Games"
- 5. In top of app you can now search for "Smart Life"
- 6. Smart Life App will appear.







- 7. Open the smart life app to add
- 8. Click Settings
- 9. Manage Smart Home Devices to verify Smart Life has been added.







10. You will be redirected to the account link page. Type in your Xodo Smart account and password, don't forget to select the country/region where your account belongs to. Then tap "Link Now" to link your Xodo Smart account. The country/region, the account, and the password must match.





Customer Service and Tech Support

Your satisfaction is important to us. We are here to help! Contact us at support@contixo.com
Include your order number and product description.
See our website for more products www.contixo.com
We enjoy your feedback!

Xodo is a subdivision of the Contixo Inc. group., and the respective logos are registered trademarks of Contixo Inc. and may not be used, reproduced, or altered without written Permission. All other trademarks are the property of their respective owners and used with permission.

To find the latest revision of this publication, visit our website at www.contixo.com