

Formula Racer SC4 User Manual



*product colors may vary


PLEASE READ THIS MANUAL BEFORE USING.
PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE

How to fill up the Smoke Chamber


Before using SC4, fill the smoke chamber with water using the included bottle. The Bottle holds twice the amount of water as the SC4's smoke chamber, so should be able to fill up the SC4's smoke chamber twice.

To fill:

1. Fill the included bottle with water.
2. Open the flap as shown in the illustration below.
3. Fill the tank with half the bottle.
4. Close the flap.



How to use the Remote Control



Auto Demo

SC4 will perform a demonstration of it's available actions (Press any key to halt the demo).

Programming Mode

Create your own set of actions! To Use the programming feature:

1. Press the programming button to enter programming mode.
2. Press the buttons of the desired actions in the order that you want them to be performed.
3. Press the programming button again and the actions selected will be performed in order.

Volume

The volume key can control the car's volume level.

Smoke Button

Short Press

SC4 will emit smoke for 50 seconds.

Long Press

SC4 will emit smoke for 120 seconds.


*product color may vary

Battery Installation

Formula Racer SC4 Battery Installation


1. Use a phillips screwdriver to unscrew the battery cover from the SC4.
2. Attach the rechargeable battery to the connector.
3. Replace the battery cover and screw back on the battery cover.

***When removing the battery to charge, take care to unclasp the connector before pulling it off.**



Remote Battery Installation

1. Use a small phillips head screwdriver to remove the battery cover.
2. Place two AA's with the corresponding polarities as labeled on the unit.



Battery Warnings

1. Batteries must be loaded with the right corresponding positive and negative electrodes.
2. Do not mix old and new batteries.
3. Do not mix different types of batteries (types or brands).

Battery Charging

1. The light turns on when charging and turns off when it is fully charged.
2. Use only the original factory cable. Do not use damaged or cable of other brands.
3. Do not charge expanded, leaked, or damaged batteries.
4. Do not overcharge the battery. When the battery is fully charged, unplug the device.
5. Do not charge near inflammable materials (eg. carpets, wood flooring, solid wood furniture, etc.).
6. Do not charge the battery immediately after it has become hot.
7. The charging temperature of the battery should be between 0-40°C (32-104°F).
8. Recommend using a 5V 1A charger (Not included) for charging.

Recycling

This equipment consists of electronic components or batteries. For electronic waste, please dispose of according to local waste disposal laws and ordinances.

Charging Time

New Battery needs to be fully charged for 180 minutes and use time is up to 20 minutes.



CONTACT INFORMATION

E-Mail: support@contixo.com

Website: www.contixo.com

©2020 Contixo Inc. All rights reserved. Contixo®, the Contixo logo and associated characters, trademarks and design elements are owned and licensed by Contixo Company.