







YX3-90S-B3
Mounting diagram





YX3-90S-B5
Mounting diagram





YX3-90S-B14
Mounting diagram





YX3-90S-B34
 Mounting diagram



YX3-90S-B35
 Mounting diagram



YX3-90S-B14B
 Mounting diagram



YX3-90S-B34B
 Mounting diagram