

**IMPORTANT! READ CAREFULLY
AND KEEP FOR
FUTURE REFERENCE**

Nuby™

Newborn 3-in-1 Baby Carrier



Instruction Manual



Newborn 3-in-1 Baby Carrier

TABLE OF CONTENTS

Baby Carrier	2-8
About Your Baby Carrier	2
Before Using Your Baby Carrier	3
How To Fasten Baby Facing Chest	4-5
How To Fasten Baby Facing Outwards	6
How To Fasten Baby In Backpack Position	7-8
Care Instructions For Your Baby Carrier	9
Product Warranty	10

ABOUT YOUR BABY CARRIER



- Carry Way: 3-in-1
- When using the soft carrier monitor your child;
- For low birthweight babies and children with medical conditions, a strong recommendation is given to seek advice from a health professional before using the product.

BEFORE USING YOUR BABY CARRIER

1. Read instructions and practice the safe opening and closing of the waist belt buckles.
2. Place the waist belt around your waist buckle and adjust.
3. Make sure you hear a "clicking" sound to ensure secure closure of the buckle.
4. Before using with baby practice fastening by placing a doll or toy inside.
5. Practice using the buckles on the shoulder strap.
6. To remove the carrier: Unbuckle the waist and chest/back strap.

To fasten baby facing chest (0m/3.5kg +):



1. Secure the waist belt by fastening the buckle until it clicks. Making sure the support rest is central to your lower back. Tighten the waist belt by pulling on the adjustable strap. The carrier should be centered on the front of your body.

2. Place the arm straps over your shoulders.



3. Fasten each buckle until it clicks. The buckles for arm straps are those at either side of your hips. Tighten the belt by pulling on the adjustable straps until the carrier is firmly in front of you.



4. Unbuckle one side of the baby carrier. Carefully lift your baby and place them into the baby carrier. Supporting babies back with your arm re-fasten the side buckles and tighten to secure. We advise that you do this with help until you are comfortable in doing so yourself.

5. Adjust the carrier so that your child is comfortable and close to your body by pulling on the adjustable straps for a snug fit around the leg openings and supporting baby.





6. Support the baby's head by attaching the two head support sliding buckle clips. To open the sliding buckle clips pinch the buttons at either side of the clip and slide over the clip button on the baby carrier straps. You will hear a 'click' when the buckle is secure. Adjust the size of the head support by pulling both the head support straps. To unfasten the sliding buckle clips pinch the buttons at either side of the clip and slide off.

To fasten baby facing outwards (5-6 months +):



Follow instructions for fastening baby facing chest at stage 4 place the baby in carrier facing outwards. Please note that baby should only be in the carrier facing outwards when 5-6 months and able to hold head upright. The front of the carrier can be buttoned down and headrest removed. **WARNING! Ensure baby can support its own head before facing outwards.**

To fasten baby in backpack position (6 to 18 months):

1. Inspect every part of the carrier and make sure the carrier is in good condition. Spread the carrier on a flat and safe surface. Place the baby onto the carrier facing upwards.



2. Fasten the buckles around the baby's waist, making sure baby's legs go through the leg openings. Fasten the buckles over the baby's shoulders, making sure arms go through the arm openings. Check all buckles are tight and secure.

3. Ensure that head support buckles are secure and adjust the straps to make sure baby's head is supported.



4. With another person's assistance, place the carrier onto your back, making sure baby is facing inwards. **WARNING! Do not attempt to do this without assistance.**



5. Place the arm straps over your shoulders, these will cross over your chest in an X shape. Fasten each buckle until it clicks. The buckles for arm straps are those at either side of your hips.

6. Tighten the belt and arm straps by pulling on the adjustable straps until the carrier is firmly and securely on your back.



WASHING INSTRUCTIONS

- We recommend spot cleaning your Nuby 3-in-1 baby carrier with a soft cloth, soap and warm water.
- Hand wash only and drip dry until fully dry.
- Do not soak or bleach. Do not use fabric softeners, or detergents.
- Do not iron, do not dry clean.

WARNING IMPORTANT SAFETY INFORMATION

Keep this instruction booklet for future reference as it includes important information.

- Your balance may be adversely affected by your movement and that of your child
- Take care when bending or leaning forward or sideways; DO NOT bend over at your waist; bend at the knees. To be carried by adults while standing or walking ONLY.
- This carrier is NOT suitable for use during sporting activities or motorised vehicles.
- The 3-in-1 baby carrier is suitable for babies with a maximum weight of 14kg (approx. -18m)
- Your child must face towards you until he or she can hold their head upright (about 5-6 months old)
- Hold your baby close at all times.
- Make sure your baby is properly positioned with their legs straddling the seat.
- Check all buckles and adjustments are secure before each use.
- Pull all straps tightly around you
- Always make sure there is enough room around baby's nose and mouth to provide clear air.
- Never lie down with your baby in the baby carrier
- Inspect the baby carrier regularly for signs of wear and tear. DISCONTINUE USE if damaged, broken or parts are missing.
- Your child MUST be able to sit upright unassisted to use the backpack position.
- Your child MUST face forward, toward the person carrying, in the backpack position.
- Small children may fall through an opening. Adjust all straps to be secure.
- Care instructions are found on the label on the baby carrier
- NEVER leave your child in the carrier unless it is being worn, as your child may fall or suffocate.
- During use check REGULARLY that your child is secure, comfortable, that their face is uncovered and that they are breathing freely.
- Keep AWAY from FIRE and strong heat sources.
- Be extra aware of hazards in the domestic environment whilst using the product, such as spilling hot drinks or objects which can be bumped into.

Product Complies: **EN:13209-2:2015**

PRODUCT WARRANTY

Nûby's '3-in-1 Newborn Baby Carrier' includes a one-year limited warranty against defects from the date of purchase. In the event of a malfunction or defect during the in-warranty period, Talbot's, at its option, will replace or repair the product under warranty. Upon receipt of the product and the proof of purchase with a valid date of purchase, the defective part will be immediately repaired or replaced and returned to you free of charge. Please send defective unit, proof of purchase with valid date of purchase, and a description of the problem you have encountered to:

Talbot's Family Products UK LLP

13 Burford Way

Boldon Business Park

Boldon Colliery

Newcastle upon Tyne

NE35 9PZ

Attn: Nûby Customer Care

Note: This warranty does not cover a defect that has been caused by negligence, accident or improper use of the product.

Questions:

Call **0800 334 5844 (UK only)** or visit

www.nuby-uk.com

enquiries@nuby-uk.com

DR.TALBOT'S

NûbyTM

Talbot's Family Products UK LLP

13 Burford Way
Baldon Business Park
Baldon Colliery
Newcastle upon Tyne
NE35 9PZ

Freephone number:
0800 334 5844

enquiries@nuby-uk.com
www.nuby-uk.com
www.nuby.com

Made in China



Form CWY_UK
Item Number: **30108**

EC REP

DC PHARM

Calle Filadores, S/N - NAVE3
Olesa de Montserrat
08640 Barcelona, SPAIN

© 2022 Talbot's.
Nûby & Nuby logo licensed to
Talbot's by Admar International.