

Magnacharge Battery Warranties

BATTERY PART NUMBER	Regular (Months)	Commercial (Months)
12 VOLT AUTOMOTIVE STARTING - TOP TERMINAL		
24C-525	18	6
24C-750	30	12
24C-925	40	18
24F-525	18	6
24F-750	30	12
24F-925	40	18
25-625	30	12
26-700	30	12
26R-700	30	12
27C-900	40	18
27F-900	40	18
34-750	30	12
34-850	40	18
35-625	30	12
36R-800	30	12
40R-750	30	12
41-800	40	18
42-550	30	12
47-750	30	12
48-850	30	12
49-1050	30	12
51-530	40	18
51R-530	40	18
58-675	40	18
58R-675	40	18
59-735	30	12
65-875	30	12
65-1100	40	18
85-650	30	12
86-650	30	12
90-625	30	12
91-820	30	12
92-800	30	12
93-995	30	12
94R-1025	30	12
95R-1050	30	12
96R-675	30	12
99R-560	30	12
121R-625	30	12
124R-850	30	12
140R-650	30	12
151R-450	30	12

Magnacharge Battery Warranties

12 VOLT AUTOMOTIVE STARTING - TOP TERMINAL		
MIATA	18	6
NS40	18	6
NS40L	18	6
NS40Z	18	6
NS60	18	6
12 VOLT AUTOMOTIVE STARTING - SIDE TERMINAL		
70-625	18	6
75-800	30	12
75-850	40	18
78-800	30	12
78-950	40	18
101-650	30	12
12 VOLT UNIVERSAL DUAL TERMINAL		
70DT-550	18	6
70DT-675	30	12
75DT-850	30	12
78DT-625	18	6
78DT-925	30	12
78DT-1000	40	18
6 VOLT COMMERCIAL TRUCK, FARM AND EQUIPMENT		
1-725	12	6
2-825	12	6
3EH-1025	12	6
4-1350	12	6
12 VOLT FARM TRACTOR AND EQUIPMENT		
3EE-525	12	6
4DLT-1125	12	12
12 VOLT COMMERCIAL TRUCK, BUS AND EQUIPMENT		
30H-850	18	18
31-875DC	12	12
31-875S	12	12
31-1125S	18	18
31-1125A	18	18
31-1250S	24	24
31-1250A	24	24
4D-1250M	18	18
4D-1250	18	18
8D-1250	12	12
8D-1600M	24	24
8D-1600	18	18
8D-1750	18	18
N-100	12	12
N-120	12	12

Magnacharge Battery Warranties

12 VOLT COMMERCIAL TRUCK, BUS AND EQUIPMENT		
64020	12	12
12 VOLT GARDEN TRACTOR & SNOWMOBILE		
U1-280	12	6
U1R-280	12	6
U1-425	12	6
U1R-425	12	6
12 VOLT AUTOMOTIVE STARTING - AGM		
24C-925AGM	42	18
24F-925AGM	42	18
31-1000AGM	20	20
31A-1000AGM	20	20
31-1125AGM	20	20
34-850AGM	42	18
35-625AGM	32	12
47-750AGM	32	12
48-950AGM	32	12
49-1050AGM	32	12
51R-530AGM	32	12
65-1000AGM	42	18
94R-1000AGM	32	12
95R-1050AGM	32	12
140R-650AGM	32	12
PRIUS	12	6