


Jonsered



IPL, 920, 1986-02, 504 99 90-20

920

Spare parts

Ersatzteile


Pièces détachées


Reserve onderdelen


Repuestos

Reservdelar

Jonsered SUPER 920














HS-219-B

SUPER Jonsered 920

- 503 08 39-01
- 501 81 50-01
- 501 77 48-01
- 503 10 85-01



CAUTION! **ATTENTION!**
For safe operation follow all safety precautions in Owner's manual. **Chaineuse can be dangerous! Les tondeuses peuvent être dangereuses!**



| | | | | | | |
|--------------|--------------|--------------|--------------|--------------|--------------|--------------|
| 501 20 15 02 | 502 01 22 01 | 504 02 00 24 | 504 21 00 23 | 504 60 20 47 | 505 26 92 75 | 734 11 46 01 |
| 501 20 87 01 | | 504 02 00 33 | 504 21 00 30 | 504 60 20 48 | 505 26 93 04 | |
| 501 22 00 01 | 503 07 85 01 | 504 02 00 36 | 504 21 00 36 | | 505 26 94 30 | 735 11 36 50 |
| 501 22 01 01 | 503 08 10 01 | 504 02 47 08 | 504 21 00 53 | 504 65 26 00 | | 735 11 46 50 |
| 501 22 02 01 | 503 08 11 01 | 504 02 49 03 | 504 21 00 54 | 504 65 55 13 | 505 29 31 62 | 735 11 53 50 |
| 501 22 03 01 | 503 08 13 02 | 504 02 52 02 | 504 21 26 01 | 504 65 55 14 | | 735 21 46 00 |
| 501 22 08 01 | 503 08 15 01 | 504 02 52 03 | | | 505 30 36 61 | 735 88 06 00 |
| 501 22 09 01 | 503 08 17 01 | 504 02 64 00 | 504 23 34 06 | 504 70 20 02 | | |
| 501 22 10 01 | 503 08 25 01 | 504 02 65 00 | | 504 71 00 03 | 505 31 07 42 | 740 42 01 00 |
| 501 22 11 01 | 503 08 39 01 | | 504 30 00 19 | 504 71 09 00 | 505 31 66 03 | 740 42 03 00 |
| 501 22 12 01 | 503 08 59 01 | 504 03 38 00 | 504 30 00 37 | | | 740 42 06 00 |
| 501 22 13 01 | 503 09 75 01 | | 504 30 00 42 | 504 72 00 21 | 720 12 68 20 | 740 42 24 00 |
| 501 22 15 01 | 503 10 21 01 | 504 05 84 00 | 504 30 00 43 | 504 72 00 22 | | |
| 501 22 17 01 | 503 10 22 01 | 504 05 85 00 | 504 30 00 45 | | 721 41 65 00 | 740 48 07 02 |
| 501 22 20 01 | 503 10 24 01 | | 504 30 00 46 | 504 73 00 43 | 721 43 03 00 | 740 48 20 03 |
| 501 22 21 01 | 503 10 85 01 | 504 06 00 24 | 504 30 00 47 | 504 73 00 44 | 721 43 10 00 | |
| 501 22 24 01 | 503 11 06 01 | 504 06 18 00 | 504 30 24 11 | 504 73 00 49 | 721 43 77 50 | 950 26 71 06 |
| 501 22 30 01 | 503 11 08 01 | 504 06 53 15 | | | 721 61 17 00 | |
| | 503 11 08 02 | 504 06 53 16 | 504 31 20 08 | 504 80 04 11 | | |
| | 503 11 55 01 | | | 504 80 31 04 | 723 12 85 05 | |
| 501 26 85 01 | | 504 09 02 01 | 504 35 71 12 | 504 80 40 00 | 723 52 24 01 | |
| 501 26 89 01 | 503 15 40 01 | | 504 35 71 18 | | | |
| 501 26 90 01 | 503 16 40 01 | 504 12 07 04 | 504 35 72 01 | 504 81 10 25 | 725 23 27 51 | |
| 501 29 86 01 | 503 16 47 01 | 504 12 08 02 | 504 35 76 08 | 504 81 10 26 | 725 52 87 55 | |
| | 503 16 58 01 | 504 12 31 09 | 504 35 86 09 | | 725 52 91 55 | |
| 501 42 71 01 | 503 17 15 01 | 504 12 31 11 | | 504 84 31 23 | 725 52 91 56 | |
| 501 46 67 01 | 503 17 16 01 | 504 12 33 01 | 504 38 10 01 | 504 84 31 24 | 725 52 93 55 | |
| 501 48 52 01 | 503 17 85 01 | 504 12 44 04 | 504 38 10 02 | | | |
| 501 48 54 01 | | 504 12 46 03 | 504 38 17 19 | 504 84 58 09 | 725 53 25 56 | |
| 501 48 56 01 | | 504 12 46 04 | 504 38 17 20 | 504 84 59 06 | 725 53 27 55 | |
| 501 51 54 01 | 503 20 00 03 | 504 12 46 07 | 504 38 17 24 | | 725 53 28 56 | |
| 501 52 04 02 | 503 20 00 16 | | 504 38 52 07 | 504 86 04 06 | 725 53 29 55 | |
| 501 52 95 02 | 503 20 00 23 | | 504 38 56 03 | 504 86 04 11 | 725 53 29 56 | |
| 501 59 79 01 | 503 20 00 24 | 504 12 50 14 | 504 38 56 04 | 504 86 04 12 | 725 53 30 55 | |
| 501 59 80 01 | 503 20 00 28 | 504 12 50 32 | | 504 86 04 13 | 725 53 31 55 | |
| 501 60 02 02 | 503 21 11 04 | 504 12 50 33 | 504 39 13 02 | | 725 53 31 56 | |
| 501 62 89 03 | 503 22 10 02 | 504 12 50 34 | | 504 88 99 52 | 725 53 32 56 | |
| 501 62 93 02 | 503 22 65 01 | | 504 44 00 42 | | 725 53 33 56 | |
| 501 63 06 01 | 503 23 00 35 | 504 13 00 27 | 504 44 00 43 | | | |
| 501 67 32 01 | 503 23 31 01 | 504 13 00 41 | | 504 90 12 02 | | |
| 501 67 35 01 | 503 23 50 07 | 504 13 00 42 | | 504 90 41 00 | 725 53 45 55 | |
| 501 67 52 01 | 503 24 10 03 | | 504 51 04 05 | 504 90 42 00 | 725 53 64 55 | |
| 501 68 89 01 | 503 25 00 02 | 504 14 62 00 | | | 725 53 70 55 | |
| 501 69 11 01 | | | 504 55 00 03 | 504 91 13 00 | | |
| 501 77 48 01 | 503 40 36 01 | 504 15 00 21 | 504 55 00 04 | | 728 74 45 05 | |
| | | | 504 55 06 00 | 504 92 02 00 | | |
| 501 81 35 01 | | 504 18 04 07 | | | 729 22 19 01 | |
| 501 81 50 01 | | 504 18 04 12 | 504 59 00 20 | 504 98 34 44 | 729 22 75 05 | |
| 501 81 74 01 | | 504 18 44 06 | 504 59 00 25 | 504 98 34 62 | | |
| 501 82 17 01 | | 504 18 45 07 | 504 59 15 00 | 504 98 34 70 | 732 21 12 22 | |
| 501 82 18 01 | | | 504 59 26 00 | 504 98 34 71 | 732 21 14 01 | |
| 501 83 44 05 | | | 504 59 27 00 | 504 98 34 73 | | |
| 501 83 45 02 | | | | | | |
| 501 91 14 01 | | | | | | |