CERAMIC COATING MAINTENANCE

PROTECT YOUR INVESTMENTS.

WEEKLY WASH MAINTENANCE

- STEP I Using Shift soap, wash vehicle utilizing the proper washing method.
- STEP 1 Dry vehicle.
- STEP 3 Wipe down with Ignition detail spray.

MONTHLY MAINTENANCE

- Stiff l- Using Shift soap, wash vehicle utilizing the proper washing method.
- STEP 2 Dry vehicle.
- STEP 3 Apply Punch-It ceramic detailer.

ANNUAL MAINTENANCE

- STEP I Using Shift soap, wash vehicle utilizing the proper washing method.
- 7 Rinse vehicle and apply Smooth Move paint decontaminator while the vehicle is wet.
- TEP 3 Re-wash vehicle with Shift soap utilizing the proper washing method.
- STEP 4 Dry vehicle.
- TIP 5 Use Slick Back primer polish and a HDO Orange Foam Pad to remove light defects.
- STEP 6 Apply Relock Express Ceramic Coating to entire vehicle.
- 5TP 7 Final wipe down with Punch-It synergy spray to add additional slickness and gloss.