

CERAMIC COATING MAINTENANCE

Mid-week maintenance (optional)

- Wipe down with Eco Shine waterless wash using the one pass/flip towel method.
- Follow with Throttle detail spray to promote self-cleaning properties of the coating.

Weekly wash maintenance

- Use Shift soap - Wash vehicle using the 2 bucket washing methods.
- Dry vehicle.
- Wipe down with Throttle detail spray.

Monthly maintenance

- Use Shift soap - Wash vehicle using the 2 bucket washing methods.
- Dry vehicle
- Apply Punch-It synergy spray

6 month maintenance

- Use Shift soap - Wash vehicle using the 2 bucket washing methods.
- Rinse vehicle and apply Smooth Move paint decontaminator while vehicle is wet.
- Re-wash vehicle with Shift soap using the 2 bucket washing methods.
- Dry vehicle.
- Apply Clutch silica spray to the entire vehicle using a soft microfiber applicator pad.
- Remove Clutch using (2) plush microfiber towels.

Annual maintenance

- Use Shift soap - Wash vehicle using the 2 bucket washing methods.
- Rinse vehicle and apply Smooth Move paint decontaminator while vehicle is wet.
- Re-wash vehicle with Shift soap using the 2 bucket washing methods.
- Dry vehicle.
- Apply Cherry silica wax to entire vehicle
- Remove the layer of Cherry silica wax using Clutch silica spray applied to a soft microfiber applicator pad.
- Remove the Clutch silica spray using (2) plush microfiber towels.

Annual maintenance option

Polishing of ceramic coating layer to remove imperfections that have developed on the surface.

- Use Slick Back primer polish to remove light defects.
- Use Burn Out reconditioning cream to remove medium/heavy defects.

Schedule an appointment with Stevens Detailing for this annual maintenance option