

Mechanical Safe Lock Operating Instructions:

1. Turn the dial counterclockwise (to the left) until the first number of your combination aligns with the 12 o'clock opening index 4 times, be sure to stop on the first number of your combination the fourth time.
2. Turn the dial clockwise (to the right) until the second number of your combination aligns with the 12 o'clock opening index 3 times, be sure to stop on the second number of your combination the third time.
3. Turn the dial counterclockwise (to the left) until the third number of your combination aligns with the 12 o'clock opening index 2 times, be sure to stop on the third number of your combination the second time.
4. Turn the dial clockwise (to the right) until the dial comes to a complete stop, and then turn the safe handle to gain access.
5. Locking your safe; Close the safe door and then spin the safe dial to the left at least 4 full turns.

If you do not successfully gain access repeat steps 1-4.

Key lock: You can use the key lock to lock the safe. In order to unlock the safe using *only* the key, the safe combination has to be dialed and left in the open/unlocked position.