


OPERATING INSTRUCTIONS

To OPEN the safe :

It is necessary to accurately dial the four numbers shown.

- A. In the correct sequence
- B. In the correct rotation, and
- C. For the correct number of turns

1. The first number must pass the opening index mark over 3 times in a clockwise (right) direction and stop on the fourth full turn.
2. The second number must pass the index mark twice in a counter-clockwise(left) direction and stop on the third full turn.
3. The third number must pass the index mark only once in a clockwise (right) direction and stop on the second full turn.
4. The fourth number must not pass the index mark turning counter-clockwise (left) and it must stop the first time it appears.
5. Now turn the key in the cylinder lock to clockwise and open the door.



To LOCK the safe :

1. Close the door
2. Turn and remove the key
3. Spin the combination lock over 3 times in any direction.

* The combination of your safe is set as follows :

NUMBER	ROTATION	TURNS
_____	Right	4
_____	Left	3
_____	Right	2
_____	Left	1

* Please do not lose the combination only you know the code.