

WARRANTY

Thank You

for purchasing Westcott gear!

Register your new gear.

We have a simple form for registering your Westcott purchase that provides you with added assurance for your gear: fjwestcott.com/warranty

Visit fjwestcott.com

- Video TIPS
- Product Support
- Knowledge Base
- Product Reviews
- Contests & More!

Our promise to you is supported by a commitment to offer the most innovative solutions, exceptional product quality and first class service and support.



One year against manufacturer defect.

Westcott's warranty obligations for this product are limited to the terms set forth below: The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the "Westcott" trademark, trade name, or logo affixed to them.

This warranty does not apply: (a) to damage caused by accident, abuse, misuse, flood, fire, earthquake or other external causes; (b) to damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) to a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) to cosmetic damage, including but not limited to scratches, dents and broken plastic.

Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the ONE (1) YEAR limited warranty will be returned at the expense of the sender.

Register this product at FJWESTCOTT.COM/WARRANTY

Repair Dept.: **800-886-1689** / 419-243-7311 (International)

E-Mail: INFO@FJWESTCOTT.COM SUBJECT: ATTN: REPAIR DEPT.

Shipping: F.J. Westcott Co, 1425 Holland Rd Suite B, Maumee, OH 43537

©F.J. WESTCOTT CO. ALL RIGHTS RESERVED. US0914



QUICK START GUIDE

SETUP & USAGE

Setting up the D5

- 1 Locate the Westcott Basics D5 light head and your preferred D5 custom softbox.



- 2 Ensure that the D5 softbox rods are located securely in each rod sleeve and corresponding rod pocket located on the interior of the softbox.

- 3 Begin mounting the D5 softbox by placing it on a flat surface with the rods separated. Place one rod into a rod receptacle located on the outer edge of the D5 light head.



- 4 Begin placing the remaining D5 softbox rods into the remaining rod receptacles, mounting corresponding rods located across from each other. The D5 custom softbox is successfully mounted to the D5 light head after all rods are placed securely into the corresponding rod receptacles.



* Please note that only every-other rod receptacle will be utilized for setup when mounting the 16" x 40" D5 Strip and the 24" x 32" D5 Rectangular Softbox as these modifiers only have four (4) rods.

- 5 After softbox mounting is complete, locate your preferred light stand and adjust the light stand height. Mount your Westcott Basics D5 to your

light stand using the D5's built-in filter bracket. Loosen the filter bracket's knob and place on the end of the light stand. Then, tighten the knob until light head is secure.



- 6 To eliminate potential light spill, ensure that the rear flaps of the softbox are sealed securely via the hook-and-loop tape.

- 7 Ensuring that the unit is not plugged in, you may now install up to five (5) daylight-fluorescent bulbs into the D5's five (5) sockets.



* Please note that the Westcott Basics D5 IS NOT compatible with tungsten-halogen bulbs. The Basics D5 is compatible with daylight-balanced fluorescent bulbs up to 85-watts each.

- 8 After installing bulbs, place the included diffusion cloth onto the front of your softbox. This is attached easily via the hook-and-loop tape located on the exterior edge of the softbox.



- 9 You may now plug the D5 in and begin shooting! The D5's output is controlled by the five (5) power switches located on the rear of the D5. Each switch controls a single D5 bulb.

Removing the D5 Softbox

- 1 Remove the diffusion front of the D5 softbox and carefully remove the fluorescent bulbs.

- 2 Loosen the knob located on the D5's tilter bracket and remove from the light stand.

- 3 Place the softbox face down on a flat surface. Gain access to the softbox rods by unsealing the rear hook-and-loop flaps.



- 4 Remove one rod from its rod receptacle by grasping firmly and pulling outward. Repeat with remaining rods until the softbox is no longer attached to the D5 light head.

- 5 Store D5 custom softboxes in their included travel cases when not in use.

CAUTION

Failure to read & follow the bullet points below may potentially void Westcott's 1-year Limited Warranty.

- Manufacturer service only: do not alter fixture or power cord.
- Please use extreme caution around children and pets until all lamps are cool.
- Always use the supplied front diffusion panel during use.
- Always make sure power is off and the power cord is unplugged before removing or inserting a lamp.
- Always disconnect the Basics D5 when not in use and allow to cool before storing and/or changing lamps.
- To avoid electrical shock, never insert any metal objects into the Basics D5 sockets.
- Never use near water and always use grounded power outlets.
- Maximum wattage is 85-watt fluorescent per socket.
- Fluorescent lamps contain mercury. Manage in accordance with disposal laws. Please visit www.lamprecycle.org