



# QUICK-MOUNT S-BRACKET

---

QUICK START GUIDE

---

## Included Components & Overview

Quick-Mount S-Bracket, Quick-Mount Plate



## Introduction

Visit the product page at [fjwestcott.com/2543](http://fjwestcott.com/2543) for more details and videos using the Quick-Mount S-Bracket.



## Warning

- Do not exceed maximum load capacities.
- Failure to secure products and together tension knobs during use could result in permanent damage of lighting gear.
- Always use weight bags when utilizing lighting equipment.
- Wipe clean with damp cloth.
- Finish subject to scratching.
- Store dry at room temperature.

## Preparing the S-Bracket

1. Loosen the following tension knobs to expand the S-Bracket:
  - Light Stand Knob
  - Tilter Bracket Knob
  - Vertical Adjustment Knob
2. Expand the bracket, then retighten the tilter and vertical adjustment tension knobs to maintain the bracket's open structure.

## Mounting the S-Bracket to a Light Stand

1. Insert the light stand spigot into the S-Bracket's  $\frac{5}{8}$ "-16 receptacle.
2. Tighten the light stand tension knob to secure.

## Mounting a Light to the S-Bracket

1. Remove the quick-mount plate from the S-Bracket tray by loosening the tension knob located on the side of the tray. (Do not unscrew completely)
2. Locate the ¼"-20 female thread on the light. With the light and plate facing forward, screw the plate into place. Do not overtighten the screw.
3. Place the plate into the tray facing forward. Adjust the light to your desired horizontal position and tighten the tray's tension knob to secure the light in place.
4. Vertically position the light within the S-Bracket's opening by loosening the vertical adjustment tension knob and sliding the opening up-and-down. Once your desired position is achieved, tighten the vertical adjustment tension knob to secure into place.

## Mounting Speedlights to the S-Bracket Perimeter

1. Ensure the speedlight shoe is in the unlocked position.
2. Completely slide the speedlight shoe into one of the S-Bracket's cold shoes on its perimeter.
3. While holding the speedlight, lock the speedlight into place by engaging the speedlight's locking mechanism.

***Note: Failure to engage the speedlight's locking mechanism may result in the speedlight separating from the bracket which can cause permanent damage.***

## Mounting a Bowens S-Type Modifier

1. Grasp the modifier's Bowens adapter and insert into the S-Bracket's Bowen's receiver.
2. Rotate clockwise until the modifier locks into place.
3. While supporting the modifier, loosen the tilter tension knob to adjust the angle of the bracket. Retighten to lock into position.

## Releasing Bowens S-Type Modifier

1. Grasp the modifier's Bowens adapter ring.
2. Slide the S-Bracket's release pin away from the modifier and rotate the Bowens adapter and modifier counterclockwise, then gently pull the modifier away from the bracket.

## Mounting an Umbrella

1. Loosen the umbrella tension knob. (Do not remove.)
2. Insert the umbrella shaft into the umbrella receptacle and slide into the desired position.
3. Tighten umbrella tension knob to secure the umbrella in place.



# Warranty

Westcott's warranty obligations for this product are limited to the following terms.

The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase from Westcott or an authorized retailer by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the Westcott trademark, trade name, or logo affixed to them.

This warranty does not apply to: (a) damage caused by accident, abuse, misuse, flood, fire, earthquake, mold, or other external causes; (b) damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) cosmetic damage, including but not limited to scratches, dents and broken plastic.

Disclaimer: By purchasing, borrowing and/or using this product for any event, both public or private, you, the customer, accepts all responsibility and releases Westcott, and its associates, of any and all liability in the event of manufacturer's defect, malfunction or misuse of the product which may lead to further injuries or complications unforeseen by the user. Westcott is not responsible for any potential or incurred damage caused by failure to properly mount, hang, or store the product, which includes, but is not limited to damage to cameras, electronics, electrical equipment, buildings, building materials, personal injury, death, or disability, fire damage, or any and all other damage not mentioned previously.

Please contact Westcott's Repair Department for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the limited warranty will be returned at the expense of the sender.

**Repair Department:** 800-886-1689 / 419-243-7311 (International)

**Email:** [service@fjwestcott.com](mailto:service@fjwestcott.com)

**Shipping:** F.J. Westcott Co, 1425-B Holland Rd. Maumee, OH 43537

Register your new gear online at [FJWESTCOTT.COM/REGISTER](https://www.fjwestcott.com/register)

Visit [FJWESTCOTT.COM](https://www.fjwestcott.com) for videos, pro tips, inspiration, and more!

Westcott products are made to the company's traditionally high standards of quality and comply with all applicable government safety regulations and requirements. In an effort to provide the best quality products possible, we periodically make product modifications. Actual products may not be identical to items pictured. Made in China. ©F.J. Westcott Co. All rights reserved. EA0321