

Womier

K75



Manufacturer: Shaodong Tongchi Technology Development Co., Ltd.
Address: No.1001 Zhaoyang Ave, Songjiatang Street, Shaodong Hunan, China



Gasket Mounted Mechanical Gaming Keyboard

中文


一、产品适用范围:

Womier(K75)机械键盘,设计82键采用RGB-灯光,产品都可运行于电脑Windows2000,WindowsXP, Vista,Win7,Win8,Win10,Win11,MAC,OS2-2.0版本以上系统。

二、硬件要求:

电脑并有连接设备可用的USB端口。

三、USB连接和键盘开关示意图



四、Womier(K75) - 机械键盘安装步骤及使用:

- 1.使用K75机械键盘时,请把键盘配备的USB TO TYPE-C连接线取出,把USB头插到电脑的USB端口上,TYPE-C头插到键盘的端口上,只要在插好线的状态下电脑会自动完成安装相关软件,并可以使用
- 2.键盘左上方靠右边设有WIN系统和MAC系统切换开关,当切换开关处在WIN位置时,则表示键盘适合是在Windows系统操作,当切换开关处在MAC位置时,则表示键盘适合是在MAC系统操作
- 3.键盘左上方靠左边是键盘灯光切换开关,当开关打在ON位置时键盘的灯光才能亮,当这开关在OFF位置时所有键盘的灯光关闭。

五、Womier(K75) - 机械键盘 FN 功能及灯光操作说明:

FN+]= 切换灯光模式	FN+END= 切换灯光颜色	FN+“↑/↓”= 灯光亮度加减调节
FN+“←/→”= 灯光呼吸或变化快慢调节	FN+CAP= 一键常亮白光, 再按退出	FN+ESC= 灯光复位

键盘支持灯光模式具体有:

随波逐流-默认,如影随行,正弦光波,旋转风车,七彩瀑布,花开富贵,常亮模式,呼吸模式,梦幻彩虹,一触即发,雨中漫步,彩虹轮盘,按键涟漪,繁星点点,踏雪无痕,川流不息。

键盘支持灯光颜色具体有:

红色-绿色-蓝色-黄色-粉色-青色-白色-混色共八种颜色。

六、K75机械键盘在MAC系统时FN多媒体功能键说明:

F1= 电脑屏幕亮度-	F2= 电脑屏幕亮度+	F3=ctrl+ 方向上
F4= 呼出siri(Command+spacean 按住1s左右释放)	F7= 上一曲	F8= 下一曲
F9= 暂停/播放	F10= 静音	F11= 音量-
F12= 音量+	注意: WIN/ALT 会在切换界面时互换,不要锁win	

K75机械键盘在WIN系统时FN多媒体功能键说明:

FN+F1= 电脑屏幕亮度-	FN+F2= 电脑屏幕亮度+	FN+F3= Calculator (计算器)
FN+F4= 电脑	FN+F5= 播放器	FN+F6= 上一曲
FN+F7= 下一曲	FN+F8= 播放/暂停	FN+F9= 停止
FN+F10= 静音	FN+F11= 音量-	FN+F12= 音量+
FN+WIN= 锁WIN键再按解除		

七、注意事项:

- 1.当使用K75机械键盘电脑无法识别使用时,应考虑端口接触不良造成,需要更换插另一个电脑USB端口使用。
- 2.当产品在使用中出现卡顿或某一个键位没功能或不动时,应考虑是轴脚松动,有可能是多次插拔接触不良造成,应把这轴拔出来看轴脚有无弯曲造成,在排除上述的原因外,如还是不能解决,请联系在线客服,我们将为您提供优质的服务。
- 3.这个产品是电子塑胶产品,所以为了产品性能稳定及使用者安全,产品只能在室内常温下使用请不要在高温或靠近火源地方使用。
- 4.产品损坏丢弃处理:如产品损坏不能修复时,请勿自行拆解或丢到火中,以免发生意外危险。应送专业废品处理站或专用回收箱进行处理。

八、物品清单:

1. TYPE-C 数据连接线一条。
2. 说明书一份

English


THE SCOPE OF APPLICATION:

Womier(K75) mechanical keyboard, design the RGB - 82 - key lighting, the product can be run on a computer, Windows, Windows xp, Vista, Windows 7, doing, Win10, Win11, MAC, OS2 system - version 2.0 above.

HARDWARE REQUIREMENTS:

The computer also has USB ports available for connecting devices.

SCHEMATIC DIAGRAM OF USB CONNECTION AND KEYBOARD SWITCH



NEW ALLIANCE K75- MECHANICAL KEYBOARD INSTALLATION STEPS AND USE:

1. When using the K75 mechanical keyboard, please take out the USB TO TYPE-C cable equipped with the keyboard, insert the USB head into the USB port of the computer, and insert the type-C head into the port of the keyboard. As long as the cable is plugged in, the keyboard can be used immediately as long as it is plugged in.
2. There is a switch between WIN system and MAC system on the upper left and right side of the keyboard. When the switch is in the WIN position, it indicates that the keyboard is suitable for operating in WINDOWS system; when the switch is in the MAC position, it indicates that the keyboard is suitable for operating in MAC system.
3. On the upper left and left of the keyboard is the keyboard light switch. When the switch is turned to the ON position, the keyboard light can be on. When the switch is turned to the OFF position, all keyboard lights will be off.

Womier(K75) - MECHANICAL KEYBOARD FN FUNCTION AND LIGHT OPERATION INSTRUCTIONS:

FN+ =Switching light modes	FN+END= Switch light colors	FN+“↑/↓”= Adjust the brightness of the light
FN+“←/→”= Light breathing or changing speedadjustment	FN+TAB= One key on the white light, and then press exit	FN+ESC= Light reset

Keyboard comes with 16 RGB lighting modes.

Keyboard has macro editing software, and you can set DIY shortcut keys and RGB lighting modes according to your preferences.

More function and LED backlight settings, please download or update the driver from the following website:

<https://www.xvxchannel.com> (Backlight settings is suitable for WIN system.)

FN MULTIMEDIA FUNCTION KEY FOR K75 MECHANICAL KEYBOARD ON MAC SYSTEM:

F1= Computer screen brightness -	F2= Computer screen brightness +	F3=CTRL + direction
F4=Call Siri (Command+Spacean press for 1s to release)	F7=In a song	F8=The next song
F9=Pause/Play	F10=Mute	F11=The volume -
F12= The volume +	Note: WIN/ALT will be interchanged when switching screens. Do not lock WIN	

English

FN MULTIMEDIA FUNCTION KEY FOR K75 MECHANICAL KEYBOARD IN WIN SYSTEM:

FN + F1= Computer screen brightness -	FN + F2= Computer screen brightness +	FN + F3= Calculator (Calculator)
FN+F4=The computer	FN + F5= Player	FN + F6=In a song
FN + F7= The next song	FN + F8= Play/Pause	FN + F9= Stop
FN + F10= Mute	FN + F11=The volume -	FN + F12=The volume +
Lock the WIN key and press it again.		

MATTERS NEEDING ATTENTION:

1. When the computer cannot recognize and use the K75 mechanical keyboard, it should be considered that the port is caused by poor contact, and it needs to be replaced and inserted into another computer USB port for use.
2. When the product is in use or a key operator didn't function or motionless, consideration should be given is loose shaft foot, may be a plug contact undesirable caused many times, should have the shaft out to see foot caused by bending, in out of the above reasons, if still can't solve, please contact the customer service of the store, and we will provide you with dedicated service.
3. This products is electronic plastic products, so in order to product performance stability and user safety, products can only be used at room temperature, please do not use in high temperature or near the fire source.

LIST OF ARTICLES:

1. One Type-C data cable.
2. One user manual.

日本語


適用範囲:

Womier K75 82キーメカニカルキーボード、RGBライト採用。Windows2000、WindowsXP、Vista、Win7、Win8、Win9、Win10、Win11、MAC、OS2 - 2.0システムに適用。

ハードウェア要件:

パソコンにキーボードが接続できるUSBポートは必要

USB接続とキーボードスイッチの概略図



Womier K75メカニカルキーボードインストール手順:

- 1.キーボードを初めて使用するとき、パッケージからUSB Type-Cケーブルを取り、キーボードをコンピュータに連結して下さい。コンピュータは差し込むことの後で使用できます。
- 2.キーボード左上の右側にWINシステムとMACシステム切替スイッチを掛け、切替スイッチがWIN位置にあるとき、キーボードはWINDOWSシステムで操作するのに適していることを示し、切替スイッチがMAC位置にあるとき、キーボードはMACシステムで操作するのに適していることを示す。
- 3.キーボードの左上の左側にキーボードライト切替スイッチがあり、スイッチがON位置にあるときにキーボードのライトが点灯し、このスイッチがOFF位置にあるときにすべてのキーボードのライトがオフになります。

K75メカニカルキーボードにFNキーの機能説明

FN+ = ライトモードを切り替える	FN+END= 照明的色を切り替える	FN+“↑/↓”= 照明的明るさ加減調節
FN+“←/→”= 照明的呼吸や変化の速度調節	FN+TAB= ボタンは常に白く光り、更に押すと退出する	FN+ESC= ライトリセット

RGBバックライトのモード: 16種類

RGBバックライトの色: 8色

弊社のソフトウェアを使用してオプションを拡張し、独自の新しいモードとエフェクトを設計できます。

ソフトウェアダウンロードリンク: <https://www.xvxchannel.com> (現在、ソフトウェアはWindows PCのみ使用できます)

MACシステム、K75メカニカルキーボードにFNキーの機能説明

F1= コンピュータの画面の明るさ	F2= パソコン画面の明るさ+	F3=ctrl+ 方向に
F4=siriを呼び出す(Command+spacean 1s程度押し解除)	F7= 前の曲	F8= 次の曲
F9= 一時停止 / 再生	F10= 静粛	F11= ボリューム-
F12= ボリューム+	注意: WIN/ALT は切替時に交換します。WIN はロックしないでください。	

WINシステム、K75メカニカルキーボードにFNキーの機能説明

FN + F1= コンピュータの画面の明るさ	FN + F2= パソコン画面の明るさ+	FN + F3= Calculator (電卓)
FN+F4= パソコン	FN + F5= プレーヤー	FN + F6= 前の曲
FN + F7= 次の曲	FN + F8= 再生 / 一時停止	FN + F9= 停止
FN + F10= 静粛	FN + F11= ボリューム-	FN + F12= ボリューム+
WINキーをロックしてから解除する。		

注意事項:

- 1.パソコンにK75メカニカルキーボードを接続できない時、ポートの接続不良可能。パソコンに別のusbポートを接続してください。
- 2.キーボードのキーが作用しない場合に、スイッチがゆるんで接触が悪くなっている可能性があるので、スイッチを抜いてみて、曲がっていないかどうか確認してください。解決できない場合に、弊社のアフターサービスにご連絡ください。
- 3.電子製品のため、キーボードを熱源や火気の近くに置かないでください。

パッケージ内容:

1. メカニカルキーボード*1
2. Type C ケーブル*1
3. 取扱説明書*1