

M75

Mechanical keyboard

User Manual



Product Basic- Wireless Version

Model Name: M75

Wireless Version: Bluetooth 5.0

Wired Interface: USB-C (1.5M Cable)

Layout: 81 Keys

Switch Type: Mechanical Switches


Battery Capacity:

8000mAh Lithium-Ion

Charging Current: DC 5V/500mA

Compatibility:


Windows 7/8/10/11, macOS 10.10+




Mode Setting and Repairing

Wired Mode

Step1. Connect the keyboard to your computer via the USB-C cable.




Step2. Toggle the power switch to the ON, briefly press "FN + 5" (the 5 - key stays white for 3S as a prompt), and you can switch to the wired connection mode.




Mode Setting and Repairing

2. 2.4G Mode

Step1. Insert the 2.4G receiver into a USB-A port on your device.




Step2. Briefly press the combination key "FN + 4" to enter the 2.4G mode (the 4 - key flashes green as a prompt), and then it will start automatic pairing.




Mode Setting and Repairing

3. Bluetooth Mode

Step1. Toggle the power switch to ON.




Step2. Long press FN + 1/2/3 for 3 seconds (the corresponding channel light flashes quickly), and select a Bluetooth channel to enter the pairing mode.





Step3. Turn on the Bluetooth of your computer or other Bluetooth devices, search for and select "M75", and click to pair to complete the connection.

Note: Bluetooth is unsupported on Windows 7 or earlier.




System & Mode Switching

Windows: Press FN+W briefly



MACOS: Press FN+A briefly





(Default is Windows system. When switching to MAC system, the overall backlight flashes yellow as a prompt; when switching to WIN system, the overall backlight flashes blue as a prompt.)

Mode Switching:

Briefly press

"FN + 1/2/3/4/5" to switch to different mode channels respectively.



Backlight Control & FN Combination Keys

FN + 	Backlight Brightness +	FN + 	Switch Light Mode
FN + 	Backlight Brightness -	FN + 	Switch Light Color
FN + 	Backlight Speed +	FN + 	Switch Left and Right Side Lights
FN + 	Backlight Speed -	FN + 	Press and Hold to Check Battery Level
FN + 	Hold for 3 seconds to restore factory settings	FN + 	Turn on/off Backlight

Package Contents :

- 1× Tri-Mode Mechanical Keyboard
- 1 x USB - C Cable
- 1 x User Manual
- 1× Keycap & Switch Puller
- 2× Replacement Mechanical Switches

Battery & Charging Guidelines

Charging Status Indicators

Wired Charging Status: The last indicator light in the lower right corner glows red, and goes out when fully charged.

Low Battery Status: Red light flashes as a prompt.

Battery Level Check: Hold FN + Left Alt - Number row lights indicate remaining capacity (0=100%).

Charging Instructions

The indicator light stays on during charging, flashes when the battery is low, and goes out when fully charged or unplugged.

Note: When the battery level is too low, the keyboard transmission may experience delays, lag, and unstable connections.

Charging Steps:

When the battery is low, the red light flashes to remind you to charge.


Connect the USB - C cable to the keyboard and then to a computer interface or a charging head for charging.

Do not use a charging device with more than 5V1A. It is recommended to use low - voltage devices such as a computer USB.



System Function of Win

FN + 	Screen Brightness-	FN + 	Next Track
FN + 	Screen Brightness+	FN + 	Play/Pause
FN + 	Open Calculator	FN + 	Stop Playback
FN + 	Open File Explorer	FN + 	Mute System Audio
FN + 	Open Media Player	FN + 	Volume-
FN + 	Previous Track	FN + 	Volume+

System Function of Mac

	Screen Brightness -		Previous Track
	Screen Brightness +		Play/Pause
	Mission Control (Multi-Window View)		Next Track
	Launchpad		Mute System Audio
			Volume -
			Volume +

Product Details Display




CAP


WIN

Charging Indicator

(stays on during charging, flashes when low on power, turns off when fully charged or unplugged)



42.21mm



2.4G Receiver

USB-C Charging Port

Power Switch

产品基本信息 - 无线版

型号：M75

无线版本：蓝牙 5.0

有线接口：USB - C (1.5M 线缆)


键位布局：81 键

轴体类型：机械轴

电池容量：8000mAh 锂离子电池

充电电流：直流 5V/500mA


兼容系统：Windows 7/8/10/11、
macOS 10.10 及以上




模式设置与连接指南

有线模式

步骤1: 通过USB-C数据线将键盘连接至电脑。




步骤2: 拨动电源开关至 ON，短按 FN+5（5键白色常亮3秒提示），切换至有线连接模式。




模式设置与连接指南

2. 2.4G模式

步骤1: 将2.4G接收器插入设备USB-A接口。




步骤2: 短按 FN+4（4键绿灯闪烁提示），进入2.4G模式并自动配对。




模式设置与连接指南

3. 蓝牙模式

步骤1: 拨动电源开关至 ON。



步骤2: 长按 FN+1/2/3 3秒（对应通道指示灯快闪），进入蓝牙配对模式。





步骤3: 开启设备蓝牙，搜索并选择“M75”，完成配对。

注意: Windows 7及以下系统不支持蓝牙连接。





系统与模式切换

Windows 系统：短按 FN + W





macOS 系统：短按 FN + A



(默认是 Windows 系统。切换到 MAC 系统时，整体背光闪烁黄色作为提示；切换到 WIN 系统时，整体背光闪烁蓝色作为提示。)

模式切换：

短按“FN + 1/2/3/4/5”
分别切换到不同的模式通道。



背光控制 & FN组合键

FN + 	背光亮度 +	FN + 	切换灯光模式
FN + 	背光亮度 -	FN + 	切换灯光颜色
FN + 	背光速度 +	FN + 	切换左右侧灯
FN + 	背光速度 -	FN + 	按住查看电量
FN + 	长按3s恢复出厂设置	FN + 	打开 / 关闭背光

包装清单:

- 1× 三模机械键盘
- 1 × USB-C 数据线
- 1 × 用户手册
- 1× 键帽轴体拔取器
- 2× 备用机械轴体

电池与充电指南

充电状态指示灯

有线充电状态：右下角最后一颗指示灯亮红光，充满后熄灭。

低电量状态：红灯闪烁提示。

电量查询：按住 FN + 左侧 Alt，数字行指示灯显示剩余电量（0 表示 100%）。

充电说明

充电时指示灯常亮，电量低时闪烁，充满或拔掉后熄灭。

注意：电量过低时，键盘传输可能会出现延迟、卡顿和连接不稳定的情况。

充电步骤：

电池电量低时，红灯闪烁提醒充电。


将 USB - C 数据线连接到键盘，再连接到电脑接口或充电头进行充电。

请勿使用超过 5V1A 的充电设备，建议使用电脑 USB 等低电压设备。


Win系统功能

FN + 	屏幕亮度-	FN + 	下一曲
FN + 	屏幕亮度+	FN + 	播放/暂停
FN + 	打开计算器	FN + 	停止播放控制
FN + 	打开文件资源管理器	FN + 	系统静音
FN + 	打开媒体播放器	FN + 	音量-
FN + 	上一曲	FN + 	音量+

Mac系统功能

	屏幕亮度-		上一曲
	屏幕亮度+		播放/暂停
	调度中心（多窗口视图）		下一曲
	启动台		系统静音
			音量-
			音量+

产品细节展示





www.xvxchannel.com



support@xvxchannel.com



[instagram.com/xvx__keyboard](https://www.instagram.com/xvx__keyboard)