

# Tie Rod Measurements

In order to get you the correct size bars, we need the following measurement. Just lay out the tie rod assembly (Inner Tie Rod, Clevis, Rod and Rod Ends) and send a photo with a tape measure from the end of the tie rod assembly where the bolt comes out that goes into the rack to the middle of the outer heim. Email it to [info@tcpor.com](mailto:info@tcpor.com)

If you have any questions feel free to give us a call at 903-504-5521

