
Read all instructions BEFORE assembly and USE of product.

KEEP INSTRUCTIONS FOR FUTURE USE. Prior to using the product, check that the product and all parts were not damaged during delivery.


BABY / DELIGHT®

# Beside Me<sup>®</sup> Doze

Deluxe Bedside Bassinet



### **Care & Instructions**



BD06110 ©2019 Baby Delight, Inc. 1-401-333-6800 www.babydelight.com

WARNING: FAILURE TO FOLLOW THESE WARNINGS AND THE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH. DO NOT USE THIS PRODUCT IF YOU CANNOT EXACTLY FOLLOW THE INSTRUCTIONS THAT COME WITH IT.

#### **FALL HAZARD**

- To help prevent falls, do not use this product when the infant begins to push up on hands and knees, can roll over, or has reached 20 lbs., (9.1 kg) whichever comes first.
- Always check that the bassinet is securely locked by pressing down on bassinet frame. Check regularly and BEFORE each use.

### **SUFFOCATION HAZARD** Infants have suffocated:


- In gaps between extra padding and side of bassinet, and
- On soft bedding.

Use only the mattress pad provided by Baby Delight, Inc. NEVER add a pillow, comforter, or another mattress for padding.


- If a sheet is used with the pad, use only the one provided by Baby Delight or one specifically designed to fit the dimension of the bassinet mattress.
- To reduce the risk of SIDS, pediatricians recommend healthy infants be placed on their backs to sleep, unless otherwise advised by your physician.

# **Assembly/Operating**

### Assembling the BASSINET:




Plug one FOOT TUBE into two FEET (one "A" foot and one "B" foot) until button clicks into place. Repeat for the other FOOT TUBE and TWO FEET.




Unfold Bassinet FRAME by spreading FRAME apart until you hear a click.

### **Assembly/Operating (Continued)**




Plug the four LEGS with the STORAGE BASKET attached into the UPPER FRAME TUBES making sure BUTTONS face inward and are clicked into place.

NOTE: The X-STRAP should be on the bottom of the STORAGE BASKET.




Click each FOOT TUBE ASSEMBLY into the LEGS making sure to click "A" FEET into "A" TUBES and "B" FEET into "B" TUBES.




Turn assembled BASSINET over and place BOARD (with hinge side facing down) and MATTRESS with SHEET inside the BASSINET.

#### Attaching the CANOPY:



Stretch CANOPY over FRAME with LOGO facing upwards.




Snap the two CANOPY BUTTONS on each side of the FRAME to secure CANOPY.


NOTE: The BUTTON attached to the triangle shaped tab should be snapped to the TOP SNAP.

# **Assembly/Operating (Continued)**


#### Folding BASSINET for Storage:



Unsnap and remove CANOPY if attached to BASSINET.



Press BUTTON GRAPHIC on each side of the FABRIC COVER, lift up slightly and start to fold down both sides of the BASSINET.




Continue folding BASSINET inward.

# ADDITIONAL WARNINGS:


- STRINGS CAN CAUSE STRANGULATION! DO NOT PLACE ITEMS WITH A
   STRING AROUND A CHILD'S NECK, SUCH AS HOOD STRINGS OR PACIFIER
   CORDS. DO NOT SUSPEND STRINGS OVER A BASSINET OR CRADLE OR
   ATTACH STRINGS TO TOYS. NEVER PLACE BASSINET NEAR WINDOW
   BLINDS OR PATIO DOORS WHERE A CHILD COULD REACH THE CORD AND
   BE STRANGLED.
- CHECK THIS BASSINET REGULARLY BEFORE USING IT, AND DO NOT USE IT IF ANY PART IS LOOSE OR MISSING OR IF THERE ARE ANY SIGNS OF DAMAGE. DO NOT SUBSTITUTE PARTS. CONTACT BABY DELIGHT, INC. IF REPLACEMENT PARTS OR ADDITIONAL INSTRUCTIONS ARE NEEDED.

# Nightlight/Sounds/Vibration Unit

#### Assembling the Nightlight/Sounds/Vibration Unit:



Unscrew BATTERY DOOR on back of UNIT and insert 3 "AA" batteries, in accordance with the +/- polarity shown, and replace BATTERY DOOR and secure with screw.



Attach UNIT on BASSINET by sliding UNIT CLIP over the BASSINET frame.

#### **Functions:**



: Press to play Brahm's Lullaby. Press again to turn sound off. Press again to play soothing sound which mimics a swooshing womb sound. Sounds automatically shut off after five minutes.



: There are 2 volume levels. Press to adjust volume.



: Press the button to turn nightlight on and off.




: There are two vibration levels. Press button to turn vibration on and again to change level. Press a third time to turn vibration off.

**WARNING!** The nightlight product is not a toy. Do not allow children to play with nightlight. Use with proper adult supervision. ALWAYS install the light on the nightlight unit only as instructed. NEVER mix old and new batteries. NEVER mix alkaline, standard, or rechargeable batteries. ALWAYS remove batteries when light is stored for an extended period of time or when batteries are exhausted. Dispose of exhausted batteries properly.


# **Care & Cleaning**

Simply use a mild soap and damp cloth to wipe down the BASSINET.


- To machine wash MATTRESS SHEET, wash on gentle cycle and air dry
- · To machine wash FABRIC COVER, wash on gentle cycle and air dry
- · To remove FABRIC COVER:



Turn BASSINET upside down.



Unsnap SIDE FLAPS (with LOGO) from FRAME.



Unzip FABRIC COVER on each end to remove, wash on gentle cycle and air dry.

To re-assemble FABRIC COVER, place back on FRAME, and re-zip on both sides of FABRIC COVER to secure. Re-snap SIDE FLAP buttons back to secure.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING! Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

### **Limited Warranty**

At Baby Delight, Inc. we make innovative and high quality products for babies, children and their parents. We warrant this product to be free from defects in material and workmanship at the time of manufacture for a period of 90-days from the date of initial purchase (sales receipt is required for proof of purchase). If a defect is discovered during the limited warranty period, we will, at our sole option, repair or replace your product at no cost to you.

This limited warranty does not cover claims resulting from misuse, failure to follow the instructions on installation, maintenance and use, abuse, alteration, involvement in an accident, and normal wear and tear.

DO NOT use BASSINET if any parts are missing, damaged, or broken. Contact Baby Delight for replacement parts and instructional literature if needed. DO NOT substitute parts.

For warranty service or replacement part information:

USA: Please call Customer Service at 1-401-333-6800, email at consumercare@babydelight.com, or mail 30 Martin Street, Suite 3C, Cumberland, RI 02864.



www.babydelight.com

©2019 Baby Delight, Inc. 1-401-333-6800 consumercare@babydelight.com