



### 3 FUNCTIONS STANDARDS 3 FUNCIONES ESTÁNDAR



## Quick change / Cambio rápido



TOUCH PANEL  
PANEL TÁCTIL

SW-1900A-3F	DPx5 #14 (DPx5#11(F,M), (DPx17#21 Thick Fabric))	3.600 S.P.M.	263 x 153 x 212 mm Machine measurements	10 Kg (Net weight ; Peso neto)

### SW-1900A-3F 0A7660Z

Direct drive electronic lockstitch button sewing machine. Equipped with touch screen panel with easy use. New designs can be created directly from the machine's panel. Included all **quick change** parts to transform the machine from button into bartacking or pattern sewing (need 1 minute to change the mechanic parts). Special designs can be created from an external computer by using software.

- 3 Functions**
1. Bartacking
  2. 30 x 40 mm pattern sewing
  3. Button sewer

**To transform the function takes only 1 minute (by operator)!!!  
No need technician!!!**

- A**
- Bartacking.
- C**
- Button sewer.

- B**
- 30 x 40 mm pattern sewing.

### SW-1900A-3F 0A7660Z

Máquina electrónica multifuncional para coser presillas, botones y costura programada dentro del campo de 40 x 30 mm. Suministrada con todas las piezas necesarias para realizar el **cambio rápido** de cualquiera de las 3 funciones. Equipada con motor servo en el cabezal, caja de control de aluminio ligera de pequeñas dimensiones y programador táctil de color que permite realizar nuevos diseños para ser cosidos en la máquina.

- 3 Funciones**
1. Presillas
  2. Campo de 40 x 30 mm
  3. Cose botones

**Cambio rápido piezas mecánicas (1 minuto)!!!  
Puede ser realizado por el operario (no precisa técnico)!!!**

- A**
- Presillas.
- C**
- Botones.

- B**
- Campo de 40 x 30 mm.