








# WARING COMMERCIAL®


*Luna* 20 Planetary Stand Mixer 20 Qt.

## WSM20L



# WARING COMMERCIAL

## Unit Components WSM20L



<b>Illustration#</b>	<b>Part#</b>	<b>Description</b>
1	037379	Screw /top front plate
2	037380	Screw /top front plate
3	038561	Top Guard (with handle)
3a	038901	Switch Acuator
3b	037717	Screw (2 required)
4	037382	Top Bowl Guard Screw (2 required)
5	038562	Bottom Guard (no handle)
6	037384	Bottom/Bowl Guard Screw (2 required)
7	037390	Washer (4 required)
8	037389	Spring Washer (4 required)
9	037388	Bolt (4 required)
10	037392	Cradle Plate (2 required one for each side)
11	037391	Hex Head Bolt with Spring Washer & Washer (6 required)
12	038563	20 Quart Bowl (WSM20LBL)
13	038564	Whisk (WSM20LW)
14	038565	Mixing Paddle (WSM20LMP)
15	038566	Dough Hook (WSM20LDH)
16	037393	Foot (4 required)
17	038567	Name Plate
18	037411	Screw (4 required)
19	037401	Attachment Hub Cover
20	037402	Attachment Hub Screw
21	037399	Start Switch (green)
22	037400	Stop Switch (red)
23	037404	Reset Switch
24	038568	Interlock Leads
25	037413	Cradle Interlock

<b>Illustration#</b>	<b>Part#</b>	<b>Description</b>
26	037415	Screw (2 required)
27	038569	Run Capacitor with Leads
28	038570	Start Capacitor with Leads
29	038571	Metal Plate
30	037412	Screw (6 required)
31	037415	Screw (2 required each side)
32	037413	Cradle Interlock
33	038575	Bracket
34	038574 038573 038572	9.25"-10"-13" Black Lead Assembly Kit 10" Black Lead Assembly 13" Black Lead Assembly
35	037421	Relay
36	037405	Cord
37	037407	Screw
38	037406	Cord Clamp
39	037408	Hex Nut
40	037387	Screw (2 required one for each side)
41	037386	Spring (2 required one for each side)
42	037385	Bowl Bracket (2 required one for each side)

<b>Illustration#</b>	<b>Part#</b>	<b>Description</b>
1	037379	Screw /top front plate
2	037380	Screw /top front plate
3	038561	Top Guard (with handle)
3a	038901	Switch Acuator
3b	037717	Screw (2 required)
4	037382	Top Bowl Guard Screw (2 required)
5	038562	Bottom Guard (no handle)
6	037384	Bottom/Bowl Guard Screw (2 required)
7	037390	Washer (4 required)
8	037389	Spring Washer (4 required)
9	037388	Bolt (4 required)
10	037392	Cradle Plate (2 required one for each side)
11	037391	Hex Head Bolt with Spring Washer & Washer (6 required)
12	038563	20 Quart Bowl (WSM20LBL)
13	038564	Whisk (WSM20LW)
14	038565	Mixing Paddle (WSM20LMP)
15	038566	Dough Hook (WSM20LDH)
16	037393	Foot (4 required)
17	038567	Name Plate
18	037411	Screw (4 required)
19	037401	Attachment Hub Cover
20	037402	Attachment Hub Screw
21	037399	Start Switch (green)
22	037400	Stop Switch (red)
23	037404	Reset Switch
24	038568	Interlock Leads
25	037413	Cradle Interlock