




STABILIZER TRIM HANDLE & PULLEY



Trim Crank Assembly



Refer to Figure A for information on items 1 & 2.



Note:

1. The Roll Pin and Weld Rod are installed as shown to ensure that the Pulley and Handle move in unison when adjusting the stabilizer.