EYEGUARD EXTENDER

Parts List:

Eyeguard Extender Housing with rubber eye guard Eyelens Cap

Installation

- 1) Pull off and save rubber eyeguard from eyepiece.
- 2) While holding lower engraved outer ring with one hand, unscrew inner top ring (containing the rubber eyeguard) just enough so the assembly slips over the eyepiece top.
- 3) While still holding the outer ring, re-tighten the inner ring until it locks onto the eyepiece.





32 Elkay Drive, Chester, New York 10918 845.469.4551 www.televue.com

EYEGUARD EXTENDER

Parts List:

Eyeguard Extender Housing with rubber eye guard Eyelens Cap

Installation

- 1) Pull off and save rubber eyeguard from eyepiece.
- 2) While holding lower engraved outer ring with one hand, unscrew inner top ring (containing the rubber eyeguard) just enough so the assembly slips over the eyepiece top.
- 3) While still holding the outer ring, re-tighten the inner ring until it locks onto the eyepiece.



