

X5说明书 (英文葡语版)  
说明书材质: 105g铜版纸  
双面印刷  
尺寸: 90\*180mm

## X5

Tranya Sports Earbuds

User Manual

V20221107

15-MONTH WARRANTY  
ACTIVATE WITHIN 14 DAYS  
tranya.com/pages/register-product  
Email: support@tranya.com

SCAN OR CODE FOR EXTENDED WARRANTY

### PACKAGE LIST

Wireless Earbud \* 2  
Magnetic Charging Case \* 1

User Manual \* 1

Ear Tips \* 3 (S/M/L)

Type-C Charging Cable \* 1

### IMPORTANT NOTES

- Register your product on [tranya.com](http://tranya.com) to get an EXTRA three-month warranty for free.
- Before using the X5 wireless earbuds, please charge both the case and earbuds.
- Three pairs of rubber eartips. Please choose the best for you.

- If both earbuds don't sync together, please reset the earbuds.
- If the earbuds don't charge, please clean the charging slot on the case and the contact surface on the earbuds.

- If the sound becomes low without control, please use tweezers to take out/remove the net inside the earbuds.

### TOUCH CONTROL

Play/Pause		Tap one time(L/R)
Previous/Next track		Tap 3 times(L/R)
Volume down/up		Tap twice(L/R)
Activate Siri/other voice control software		Touch and hold for 1 second (L/R)
Answer a call		Tap one time(L/R)
Reject/End a call		Touch and hold for 1 second(L/R)
Game Mode <small>(Automatically return to normal mode after power off)</small>		Tap 4 times(L/R)

### POWER ON

Automatically

Manually

(Long touch and hold BOTH earbuds for 4 seconds until blue light blink)

### POWER OFF

Automatically

Manually

(Long touch and hold any one of the earbuds for 4 seconds until white light blink)

**Note:** When the charging case is at low battery or out of power, the earbuds will not automatically power on/off, please turn them on/off manually.

### WEARING

- Put the earbuds into your ears.
- Rotate the earbuds till the end of the ear hook is inserted behind the ear.

### CONNECT THE EARBUDS

- Power on the earbuds and turn on the Bluetooth in your phone.
- Select "X5" and confirm.

### CHARGING

- Charging the Earbuds
- Charging the Case with Type-C Cable(included)

### HOW TO RESET THE EARBUDS

If your earbuds stop syncing with each other, please follow below steps to reset the earbuds:

- Put both earbuds back into the charging case.
- Touch and hold BOTH earbuds 8s until BOTH blue lights blink 3 times.
- The earbuds will sync together and enter the pairing mode automatically.

### FAQ

Q: Why does signal interruption occur in some places, such as along the railway and the airport?

A: There are usually lots of underground cable lines along the places mentioned above, which might cause electromagnetic interference and result in a signal interruption.

Q: My earbuds don't charge, what can I do?

A: Please try to follow below steps:  
1. Clean the charging slot. 2. Clean the charging connector on earbuds.

Q: Why won't my earbuds power on/off automatically?

A: The earbuds would not power off automatically when the case is at a low battery or out of power. Please recharge the case. And you can long touch for 4 seconds to power on and long touch for 4 seconds to power off the earbuds.

Q: Will the Bluetooth mouse cause signal interference?

A: Perhaps, When your Bluetooth mouse and earbuds are connected to the same device, it might happen.

For more information, please visit:  
[tranya.com](http://tranya.com)

For any assistance, email us:  
[support@tranya.com](mailto:support@tranya.com)

Made in China  
FC CE RoHS

EC REP

Authorized Consulting GmbH  
Bismarckstr. 20  
10247 Frankfurt am Main, Germany  
contact@consultmaster.com  
021\_81\_20221107@tranya.com

UK AR

UK HEAD OFFICE  
3 Dale Street, Salford,  
Greater Manchester, M6 4PU,  
United Kingdom

## X5

Fone de Ouvido Tranya Sport

Manual do Usuário

V20221107

15 MESES GARANTIA ATIVAR DENTRO DE 14 DIAS  
tranya.com/pages/register-product  
Email: bra@tranya.com

SCAN OR CODE FOR EXTENDED WARRANTY

### CONTEÚDO DA CAIXA

Fone sem Fio \* 2  
Estojo de Carregamento \* 1

Manual do Usuário \* 1

Ponteiras de Borracha \* 3 (S/M/L)

Cabo de Carregamento Type-C \* 1

### INFORMAÇÕES IMPORTANTES

- Registre o seu produto em [tranya.com](http://tranya.com) para ganhar três meses de garantia EXTRA.
- Antes de usar os fones X5, carregue o estojo e os fones.
- 3 pares de ponteiros de borracha. Escolha a melhor para você.

- Se os fones não sincronizarem, por favor reset os fones.
- Se os fones não carregarem, por favor limpe o slot no estojo de carregamento e a superfície de contato dos fones com um cotonete.

- Se o som ficar baixo e abafado, utilize uma pinça para remover a rede interna dos fones de ouvido.

### CONTROLE DE TOQUE

Play/Pause		Toque 1 vez (L/R)
Anterior/Faixa Próxima		Toque 3 vezes (L/R)
Diminuir/Aumentar Volume		Toque 2 vezes (L/R)
Ativar Siri/outra assistente de voz		Toque e segure por 1 segundo (L/R)
Atender Chamada		Toque 1 vez (L/R)
Rejeitar/Encerrar Chamada		Toque e segure por 1 segundo (L/R)
Modo Jogo <small>(Retorna automaticamente ao modo normal após desligar)</small>		Toque 4 vezes (L/R)

### LIGANDO

Automaticamente

Manualmente

(Pressione e segure AMBAS por 4 segundos)

### DESLIGANDO

Automaticamente

Manualmente

(Pressione e segure CADA por 4 segundos)

**Nota:** Quando o estojo de carregamento estiver com pouca ou nenhuma carga, os fones não ligam/desligam automaticamente. Por favor, desligue-os manualmente.

### USANDO

- Coloque os fones dentro dos ouvidos.
- Gira os fones de ouvido até que a extremidade do gancho de fixação fique atrás da orelha.

### CONECTANTO OS FONES

- Ligue os fones e ligue o Bluetooth no seu celular.
- Selecione "X5" e confirme.

### CARREGANDO

- Carregando os fones
- Carregando o estojo com o cabo Tipo C (incluído)

### COMO RESETAR OS FONES

Se os fones pararem de sincronizar um com o outro, por favor siga os passos abaixo para resetá-los:

- Retire ambos os fones e desligue-os.
- Pressione e segure ambos os fones por 8s até os leds azul.
- Os fones serão sincronizados e entrarão em modo de pareamento automaticamente.

### FAQ

Q: Por que a interrupção do sinal ocorre em alguns lugares, como ao longo do metrô ou aeroporto?

A: Geralmente, há muitos cabos subterrâneos nos lugares mencionados acima, portanto são mais propensos a produzir interferência eletromagnética, que resulta na interrupção do sinal.

Q: Meus fones não carregam, o que posso fazer?

A: Por favor, tente os seguintes passos abaixo:  
1. Limpe o slot de carregamento do estojo. 2. Limpe o conector de carregamento dos fones.

Q: Por que meus fones não ligam ou desligam automaticamente?

A: Os fones podem não desligar automaticamente quando o estojo está com pouca ou nenhuma carga. Por favor, recarregue o estojo. Você também pode pressionar por quatro segundos para ligar ou desligar manualmente.

Q: Mouses Bluetooth podem causar interferência no sinal?

A: Talvez, se o mouse Bluetooth e os fones estiverem conectados no mesmo dispositivo, isso poderá ocorrer.

Para mais informações, por favor visite:  
[tranya.com](http://tranya.com)

Para qualquer assistência, envie-nos um e-mail:  
[bra@tranya.com](mailto:bra@tranya.com)

Made in China  
FC CE RoHS

## Tranya

Manufacture:  
Name: CHANDASUNG TECH (SHENZHEN) CO.,LTD  
Address: Rm 802, Building B, Zhonghengsheng High-tech Zone,  
No.3 Xinyu Road Xinqiao Street, Bao'an District, Shenzhen, China.